

Troubleshooting for POSTEK RFID Printers

RFID	Error Code	Explanation	Solution
ON RFID LABEL	VOID0	Fails to read any RFID label	Increase the RFID read power and test print&encode directly.
	VOID1	Fails to write RFID label	1) Check whether the RFID label is locked; 2) Check whether the encoding data exceeds the chip memory; 3) Check the data format is correct or not, usually it should be 4 bytes or multiples of 4 bytes; 4) Check whether it's special label, which can only be encoded for once; 5) If all above situations are exclueded, for TXR series printers, decrease the RFID write power and test print&encode directly.
	VOID2	Fails to read the next RFID label	Set the RFID OFFSET value manually: measure the distance between the RFID chip and the leading edge of the label, and manually input the RFID offset value, then test print&encode directly.
	VOID3	Multiple RFID labels are read	Decrease the RFID read power test print&encode directly.
ON LCD Display	RFID ERROR 01-14	RFID Calibration Error	 Perform RFID calibration again; Set the RFID OFFSET value manually and icnrease the RFID read power, and print&encode directly.
RFID Offset Measurement		Label Height Gap	RFID Chip Print Direction
Operation Steps		the PAUSE button please adjust 2 dB calibration again, To perform RFID c then perform med tags after calibrati button, the printe	ralibration, please press the MEDIA CALIBRATION button, the printer would dia calibration and RFID calibration automatically. Please roll back the RFID ion manually and place the first label on top of the platen roller, press FEED r would feed one label and stop at correct postion.