



1) After install the OPOS and run the setup.



2) Please Select the device and select the actual port.


2.1) Make sure the Baud rate is correct.

2.2) Click setup for next step.



3) Select the VFD name.

3.1) Click claim and enable function.



4) Type in the display.

4.1) Click the “ Display Text” for do the test.