

**Thermal Receipt Printer** 

# **PROGRAM MANUAL**

# 1. COMMANDS

# **1.1 Command Notation**

[Name]	The name of the command.				
[Format]	The code sequence.ASCII,Hex, Decimal 3 kinds of formats, default Decimal format.				
[Range]	Gives the allowable ranges for the arguments.				
[Description	] Describes the command's function.				
[Details]	Describes the usage of the command in detail.				
[Notes]	Provides important information on setting and using the printer command, if necessary.				
[Default]	Gives the default values, if any, for the command parameters.				
[Reference] Lists related commands.					

# <u>2. HT</u>

[Name]	Horizontal tab								
[Format]	ASCII HT								
	Hex 09								
	Decimal 9								
[Description] [Details]	<ul> <li>Moves the print position to the next horizontal tab position.</li> <li>This command is ignored unless the next horizontal tab position has been set.</li> <li>If the next horizontal tab position exceeds the printing area, the printer sets the printing position to [Printing area width + 1].</li> <li>Horizontal tab positions are set with ESC D.</li> <li>If this command is received when the printing position is at [printing area width + 1], the printer executes print buffer-full printing of the current line and horizontal tab processing from the beginning of the next line.</li> <li>The default setting of the horizontal tab position for the paper roll is font A (12 × 24) event 8th character (0th 17th 25th column)</li> </ul>								
[Reference]	ESC D								
<u>3. LF</u>									
[Name]	Print and line feed								
[Format]	ASCII LF								
	Hex 0A								
	Decimal 10								
[Description]	Prints the data in the print buffer and feeds one line based on the current line spacing.								
[Note]	This command sets the print position to the beginning of the line.								
[Reference]	ESC 2, ESC 3								

<u>4. FF</u>								
[Name]	Print and return to standard normal mode in page mode							
[Format]	ASCII	FF						
	Hex	0C						
	Decimal	12						
[Description]	Prints the	data in the print buffer collectively and returns to normal mode.						
[Details]	<ul> <li>The buffer data is deleted after being printed.</li> </ul>							
	<ul> <li>The printing area set by ESC W is reset to the default setting.</li> </ul>							
	<ul> <li>The printer does not execute paper cutting.</li> </ul>							
	<ul> <li>This command sets the print position to the beginning of the line.</li> </ul>							
	<ul> <li>This command is enabled only in page mode.</li> </ul>							
[Reference]	ESC FF, ES	SC L, ESC S						

# 5. CAN

[Name]	Cancel prir	Cancel print data in page mode					
[Format]	ASCII	CAN					
	Hex	18					
	Decimal	24					
[Description]	In page mo	de, deletes all the print data in the current printable area.					
[Details]	<ul> <li>This command is enabled only in page mode.</li> </ul>						
	<ul> <li>If data that existed in the previously specified printing area also exists in the</li> </ul>						
	currently specified printing area, it is deleted.						
[Reference]	ESC L, ES	ESC L, ESC W					

# <u>6. DLE EOT n</u>

[Name]	Real-time status transmission								
[Format]	ASCII	DLE	EOT	n					
	Hex	10	04	n					
	Decimal	16	4	n					
[Range]	$1 \le n \le 4$								
[Description]	Transmits	the seled	cted print	er status spec	cified by r	n in real-tin	ne, accore	ding to the	
	following	paramet	ers:						
	n = 1	: Transm	nit printer	status					
	n = 2: Transmit off-line status								
	n = 3: Transmit error status								
	n = 4: Transmit paper roll sensor status								
[Details]	<ul> <li>The status is transmitted whenever the data sequence.</li> </ul>								
	<ul> <li>This command should not be used among the command that consists of 2 or more bytes.</li> </ul>								
	<ul> <li>Even though the printer is not selected using ESC = (select peripheral device), this command is effective.</li> </ul>								
	<ul> <li>The prir data.</li> </ul>	nter trans	mits the	current status	. Each sta	atus is rep	resented	by onebyte	

- The printer transmits the status without confirming whether the host computer can receive data.
- The printer executes this command upon receiving it.
- This command is ony available for serial port printer. The printer executes this command upon receiving it any status.

Bit	0/1	Hex	Decimal	Function
0	0	00	0	Fixed to "0".
1	1	02	2	Fixed to "1".
2	0	00	0	One or two drawer open
	1	04	4	Two drawers closed
3	0	00	0	On-line
	1	08	8	Off-line
4	1	10	16	Fixed to "1".
5,6				Undefined.
7	0	00	00	Fixed to "0".

n = 1: Printer status

### n = 2: Off-line status

Bit	0/1	Hex	Decimal	Function
0	0	00	0	Fixed to "0"
1	1	02	2	Fixed to "1".
2	0	00	0	Cover is closed.
	1	04	4	Cover is open.
3	0	00	0	Not press FEED button.
	1	08	8	press FEED button
4	1	10	16	Fixed to "1"
5	0	00	0	No paper-end
	1	20	32	Paper end
6	0	00	0	No error.
	1	40	64	Error occurs.
7	0	00	0	Fixed to "0"

## n = 3: Error status

Bit	0/1	Hex	Decimal	Function
0	0	00	0	Fixed to "0"
1	1	02	2	Fixed to "1"
2	-	-	-	Undefined.
3	0	00	0	No auto-cutter error.
	1	08	8	Auto-cutter error occurs.
4	1	10	16	Fixed to "1"
5	0	00	0	No unrecoverable error.
	1	20	32	Unrecoverable error occurs.

6	0	00	0	Normal print head temperature and voltage
	1	40	64	Abnormal print head temperature and voltage
7	0	00	0	Fixed to "0"

n = 4: Continuous paper sensor status

		· ·		
Bit	0/1	Hex	Decimal	Function
0	0	00	0	Fixed to "0".
1	1	02	2	Fixed to "1".
2,3	0	00	0	Paper enough
	1	0C	12	Paper near-end
4	1	10	16	Fixed to "1".
5,6	0	00	0	Paper enough
	1	60	96	Paper end
7	0	00	0	Fixed to "0".

[Reference]

DLE ENQ, GS a, GS r

# 7. DLE ENQ n

[Name]	Re	al-tim	e requ	est to pi	inter				
[Format]	ASC		DLE	ENQ	n				
	Hex		10	05	n				
	Dec	cimal	16	5	n				
[Range]	1 ≤ r	n ≤ 2							
[Description]	Resp	oonds	to a re	equest f	rom the host computer. n specifies the requests as				
	follo	ows:							
	n	Requ	est						
	1	Reco	ver fro	m an eri	ror and restart printing from the line where the error occurred				
	2	Reco	ver fro	m an eri	ror after clearing the receive and print buffers				
[Details]	This command is effective only when an auto-cutter error occurs.								
	• The printer starts processing data upon receiving this command under serial port.								
	• With a parallel interface model, this command can not be executed when the								
	printer is busy.								
•	This command should not be contained within another command that consists								
	of two or more bytes.								
• `	When the printer is disabled with <b>ESC =</b> (Select peripheral device), the error								
	recovery functions (DLE ENQ 1 and DLE ENQ 2) are enabled, and the other								
	functions are disabled.								
• '	When the pulse is output to the connector pin specified while ESC p or DEL								
	<b>DC4</b> is executed while this command is processed, this command is ignored.								
•	The printer executes this command upon receiving it under serial port.								
• `	With a	paral	lel inte	rface m	odel, this command cannot be executed when the				
F	orinter	is bus	sy.						

• If print data includes the same character strings as this command, the printer

performs the same operation specified by this command. The user must consider above condition.

- This command should not be used within the data sequence of another command that consists of 2 or more bytes.
- This command is effective even when the printer is disabled with **ESC** = (Select peripheral device).

[Reference] ESC p

# 8. ESC FF (\*)

[Reference]	FF, ESC	FF, ESC L, ESC S					
	ESC 1	and ES	SC W, and the position for buffering character data.				
	<ul> <li>After printing, the printer does not clear the buffered data, setting values for</li> </ul>						
[Details]	• This c	ommand	l is enabled only in page mode.				
[Description]	In page n	node, pri	ints all buffered data in the printing area collectively.				
	Decimal	27	12				
	Hex	1B	OC				
[Format]	ASCII	ESC	FF				
[Name]	Print data	in page	mode				

# 9. ESC SP n

[Name]	Set right-side	characte	r spacing							
[Format]	ASCII	ESC	SP	n						
	Hex	1B	20	n						
	Decimal	27	32	n						
[Range]	0 ≤ <i>n</i> ≤ 255									
[Description]	Sets the chara vertical motion	acter spa n units].	cing for th	e right side of the character to [ n $\square$ $\square$ horizontal or						
[Details]	<ul> <li>When chain times normal</li> </ul>	racters a al value.	re enlarge	d n times, the right-side character spacing is n						
	<ul> <li>This command sets values independently in each mode (standard and page modes).</li> </ul>									
	<ul> <li>The horizontal and vertical motion unit are specified by GS P. Changing the horizontal or vertical motion unit does not affect the current right-side spacing.</li> </ul>									
	<ul> <li>The GS P command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of the minimum horizontal movement amount.</li> </ul>									
	<ul> <li>In standard mode, the horizontal motion unit is used.</li> </ul>									
	<ul> <li>In page mode, the horizontal or vertical motion unit differs in page mode, depending on starting position of the printable area as follows:</li> <li>1 When the starting position is set to the upper left or lower right of the</li> </ul>									
	printable area using <b>ESC T</b> , the horizontal motion unit (x) is used. 2 When the starting position is set to the upper right or lower left of the printable area using <b>ESC T</b> , the vertical motion unit (y) is used.									
	• The maximu exceeding the	ım right-s e maximu	side spaci m is conv	ng is 31.91mm (255/203) inches. Any setting erted to the maximum automatically.						
[Default]	<i>n</i> = 0									
[Reference]	GS P									

10. ESC ! *n* 

[Name]	Select prir	Select print mode(s)							
[Format]	ASCII	ESC	!	n					
	Hex	1B	21	n					
	Decimal	27	33	n					
[Range]	$0 \leq n \leq$	255							

[Range]

[Description] Selects print mode(s) using n as follows:

Bit	1/0	Hex	Decimal	Function
0	0	00	0	Character font A (12 $ imes$ 24).
	1	01	1	Character font B (9 $ imes$ 17).
1	-	-	-	Undefined.
2	-	-	-	Undefined.
3	0	00	0	Emphasized mode not selected.
	1	08	8	Emphasized mode selected.
4	0	00	0	Double-height mode not selected.
	1	10	16	Double-height mode selected.
5	0	00	0	Double-width mode not selected.
	1	20	32	Double-width mode selected.
6	-	-	-	Undefined.
7	0	00	0	Underline mode not selected.
	1	80	128	Underline mode selected.

[Details]

· When both double-height and double-width modes are selected, quadruple size characters are printed.

- The printer can underline all characters, but can not underline the space set by HT or 90° clockwise rotated characters.
- The thickness of the underline is that selected by **ESC**  $\Box$  , regardless of the character size.
- When some characters in a line are double or more height, all the characters on the line are aligned at the baseline.
- ESC E can also turn on or off emphasized mode. However, the setting of the last received command is effective.
- ESC can also turn on or off underline mode. However, the setting of the last received command is effective.
- · GS ! can also select character size. However, the setting of the last received command is effective.
- Emphasized mode is effective for alphanumeric and Kanji. All print modes except emphasized mode is effective only for alphanumeric.

[Default] n = 0

[Reference] ESC -, ESC E, GS !

#### 11. ESC \$ nL nH

[Name]	Set absolu	te print po	osition						
[Format]	ASCII	ESC	\$	nL	nH				
	Hex	1B	24	nL	nH				
	Decimal	27	36	nL	nH				
[Range]	$0 \le nL \le 255$								
	0 ≤ <i>nH</i> ≤ 255								
[Description]	Sets the distance from the beginning of the line to the position at which								

	subsequent characters are to be printed.
	<ul> <li>The distance from the beginning of the line to the print position is</li> </ul>
	[( $nL$ + $nH$ $ imes$ 256) $ imes$ (vertical or horizontal motion unit)] inches.
[Details]	<ul> <li>Settings outside the specified printable area are ignored.</li> </ul>
	<ul> <li>The horizontal and vertical motion unit are specified by GS P.</li> </ul>
	• The GS P command can change the horizontal (and vertical) motion unit.
	However, the value cannot be less than the minimum horizontal movement
	amount, and it must be in even units of the minimum horizontal movement
	amount.
	<ul> <li>In standard mode, the horizontal motion unit (x) is used.</li> </ul>
	<ul> <li>In page mode, horizontal or vertical motion unit differs depending on the starting position of the printable area as follows:</li> </ul>
	1 When the starting position is set to the upper left or lower right of the printable area using <b>ESC T</b> , the horizontal motion unit (x) is used.
	2 When the starting position is set to the upper right or lower left of the printable area using <b>ESC T</b> , the vertical motion unit (y) is used.
[Reference]	ESC  GS \$, GS  GS P

# <u>12. ESC % n</u>

[Name]	Select/cance	l user-d	lefined	cha	aract	er set			
[Format]	ASCII	ESC	%		n				
	Hex	1B	25		n				
	Decimal	27	37		n				
[Range]	$0 \le nL \le 255$								
[Description]	<ul> <li>Selects or cancels the user-defined character set.</li> <li>When the LSB of <i>n</i> is 0, the user-defined character set is canceled.</li> <li>When the LSB of <i>n</i> is 1, the user-defined character set is selected.</li> </ul>								
	<ul> <li>automatical</li> <li><i>n</i> is availab</li> </ul>	lly selec	ted. for the	elea	ist sig	gnificant bit.			
[Default]	<i>n</i> = 0								
[Reference]	ESC &, ESC	?							
<u>13. ESC &amp; y</u>	c1 c2 [x1 d1	d(y >	<b>√</b> □ x1	)][	xk d	1d(y X xk)]			
[Name]	Define user-o	defined	charad	cters	5				
[Format]	ASCII	ESC	&	y	c1	c2 [ $ imes$ 1 d1d(y $ imes$ x1)][xk d1d(y $ imes$ xk)]			
	Hex	1B	26	y	с1	c2 [ $ imes$ 1 d1d(y $ imes$ x1)][xk d1d(y $ imes$ xk)]			
	Decimal	27	38	y	c1	c2 [ $ imes$ 1 d1d(y $ imes$ x1)][xk d1d(y $ imes$ xk)]			
[Range]	<i>y</i> = 3								
	$32 \leq c1 \leq c2$	≤ 126							
	$0 \le x \le 12$ Fo	nt A (12	2  imes 2	4)					
	$0 \le x \le 9$ Font B (9 $\times$ 17)								
	$0 \leq d1 \dots d(y \times xk) \leq 255$								
[Description]	Defines user-	defined	l chara	icte	rs.				
	<ul> <li><i>y</i> specifies the number of bytes in the vertical direction.</li> <li><i>c1</i> specifies the beginning character code for the definition, and <i>c</i>2 specifies the final code.</li> </ul>								
[Details]	<ul> <li>x specifies</li> <li>The allows characters)</li> <li>It is possible If only one of d is the dot</li> </ul>	able cha able cha e to def characte data fo	fine mi er is do or the c	ultip sire	le ch ed, u acter	ange is from ASCII code <20>H to <7E>H (95) earacters for consecutive character codes. se $c1 = c2$ . rs. The dot pattern is in the horizontal direction			

from the left side. Any remaining dots on the right side are blank.

- The data to define a user-defined character is (y imes x) bytes.
- Set a corresponding bit to 1 to print a dot or 0 to not print a dot.
- This command can define different user-defined character patterns by each fonts. To select a font, use **ESC** !
- A user-defined character and a downloaded bit image cannot be defined simultaneously. When this command is executed, the downloaded bit image is cleared.
- The user-defined character definition is cleared when:
  - 1) **ESC** @ is executed.
  - 2 **ESC** ? is executed.
  - ③ **FS q** is executed.
  - ④ **GS** \*is executed.
- (5) The printer is reset or the power is turned off.
- When the user-defined characters are defined in font B (9  $\times$  17), only the most significant bit of the 3rd byte of data in vertical direction is effective.

[Default] The internal character set

[Reference] ESC %, ESC ?

[Example]

• When font A (12 imes 24) is selected.



• When font B (9 imes 17) is selected.



# <u>14. ESC \* m nL nH d1... dk</u>

[Name]	Select bit-image mode							
[Format]	ASCII	ESC	*	т	nL	nH	d1dk	
	Hex	1B	2A	т	nL	nH d	1dk	
	Decimal	27	42	т	nL	nH d	1dk	
[Range]	m = 0, 1, 32	2, 33						
	$0 \le nL \le 255$							
	$0 \le nH \le 3$							

#### $0 \le d \le 255$

[Description] Selects a bit-image mode using m for the number of dots specified by *nL* and *nH*, as follows:

		Vertical Dire	ction	Horizontal Direction		
m	Mode	Number of	Dot	Dot	Number of Data	
		Dots	Density	Density	(К)	
0	8-dot single-density	8	67 DPI	100 DPI	nL + nH $ imes$ 256	
1	8-dot double-density	8	67 DP	200 DPI	nL + nH $ imes$ 256	
32	24-dot single-density	24	200DPI	100 DPI	(nL + nH $ imes$ 256) $ imes$ 3	
33	24-dot double-density	24	200 DPI	200DPI	(nL + nH $ imes$ 256) $ imes$ 3	

#### [dpi:dot/25.4mm{1"}]

[Details]

- If the values of *m* is out of the specified range, *nL* and data following are processed as normal data.
- The nL and nH indicate the number of dots of the bit image in the horizontal direction. The number of dots is calculated by  $nL + nH \times 256$ .
- If the bit-image data input exceeds the number of dots to be printed on a line, the excess data is ignored.
- *d* indicates the bit-image data. Set a corresponding bit to 1 to print a dot or to 0 to not print a dot.
- If the width of the printing area set by **GS L** and **GS W** less than the width required by the data sent with the **ESC \*** command, the following will be performed on the line in question (but the printing cannot exceed the maximum printable area):
  - ① The width of the printing area is extended to the right to accommodate the amount of data.
  - ② If step ① does not provide sufficient width for the data, the left margin is reduced to accommodate the data.
- After printing a bit image, the printer returns to normal data processing mode.
- This command is not affected by print modes (emphasized, double-strike, underline, character size or white/black reverse printing), except upside-down printing mode.
- The relationship between the image data and the dots to be printed is as follows:
- When 8-dot bit image is selected:



• When 24-dot bit image is selected



# <u>15. ESC – n</u>

[Name]	Turn und	derline mod	e on/off							
[Format]	ASCII	ESC	-	n						
	Hex	1B	2D	n						
	Decimal	27	45	n						
[Range]	$0 \le n \le 2$	$1, 48 \le n \le 5$	0							
[Description]	Turns ur	nderline mo	de on or	off, based or	n the following va	alues of <i>n</i> :				
	n	Function				]				
	0, 48	Turns off underline mode								
	1, 49	Turns on u	Turns on underline mode (1-dot thick)							
	2, 50	Turns on u	underline	mode (2-dot	ts thick)					
[Default]	<ul> <li>The p but cal</li> <li>The pr inverte</li> <li>When followi mode</li> <li>Chang</li> <li>Underl that the</li> <li>This co</li> </ul>	<ul> <li>The printer can underline all characters (including right-side character spacing), but cannot underline the space set by HT.</li> <li>The printer cannot underline 90 clockwise rotated characters and white/black inverted characters.</li> <li>When underline mode id turned off by setting the value of n to 0 or 48, the following data is not underlined, and the underline thickness set before the mode is turned off does not change. The default underline thickness is 1 dot.</li> <li>Changing the character size does not affect the current underline thickness.</li> <li>Underline mode can also be turned on or off by using ESC !. Note, however, that the last received command is effective.</li> </ul>								
	n = 0									
[Reference]	ESC !									
16. ESC	2									

## <u>16.</u>

[Name]

Select default line spacing

[Format]	ASCII	ESC	2				
	Hex	1B	32				
	Decimal	27	50				
[Description]	Selects 3.75r	mm line sp	acing.				
[Details]	•The line spacing can be set independently in standard mode and in page mode.						
[Reference]	ESC 3						

# <u>17. ESC 3 n</u>

[Name]	Set line spa	cing		
[Format]	ASCII	ESC	3	n
	Hex	1B	33	n
	Decimal	27	51	n
[Range]	$0 \le n \le 255$			
[Description] [Details]	<ul> <li>Sets the line</li> <li>The line</li> <li>The horiz horizontal</li> <li>The GS F However, amount, a amount.</li> <li>In standar</li> <li>In standar</li> <li>In page m position of ① When printal</li> <li>② When able a</li> <li>The maxin more than paper only</li> </ul>	e spacing t spacing ca ontal and or vertical comman the value and it must d mode, th ode, this c f the printa the startin ble area us the startin the startin strea using num paper 956mm is y 956mm.	to [n ] an be sivertical motior d can c cannot be in e the vertic comman ble are g positi ESC T feed a set, the	<ul> <li>vertical or horizontal motion unit] inches.</li> <li>et independently in standard mode and in page mode.</li> <li>motion unit are specified by <b>GS P</b>. Changing the</li> <li>n unit does not affect the current line spacing.</li> <li>hange the horizontal (and vertical) motion unit.</li> <li>be less than the minimum vertical movement</li> <li>even units of the minimum vertical movement</li> <li>cal motion unit (y) is used.</li> <li>nd functions as follows, depending on the starting</li> <li>a:</li> <li>on is set to the upper left or lower right of the</li> <li><b>C T</b>, the vertical motion unit (y) is used.</li> <li>on is set to the upper right or lower left of the print</li> <li>the horizontal motion unit (x) is used.</li> <li>umount is 956mm . Even if a paper feed amount of</li> <li>e printer feeds the</li> </ul>
[Default]	Line spacin	g equivale	nt to ap	pproximately 3.75mm.
[Reference]	ESC 2, GS	Ρ		

# <u>18. ESC = n</u>

[Name]	Cho	oose printe	ər			
[Format]	AS	CII E	SC =	: n		
	Hex	1B	3D	n		
	Decim	al 27	61	n		
[Range]	0 ≤	□ <i>n</i> ≤ 1				
[Description]	Sele	ects device	e to whic	h host com	puter sends data, u	sing <i>n</i> as follows:
			Hex	Decimal	Function	
	Bit	1/0				
	0	0	00	0	Printer disabled	
	0	1	01	1	Printer enabled	
	1-7	-	-	-	Undefined	
[Details]	□ □ W	hen the pi <b>r</b>	nter is dis	sabled, it ig	nores all data excep	t for error-recovery commands
	(DLE EC	DT, DLE E	NQ, DLI	E DC4).		

[Default] n = 1

# <u>19. ESC ? n</u>

[Name]	Cancel user-defined characters						
[Format]	ASCII	ESC	?	п			
	Hex	1B	3F	n			
	Decimal	27	63	n			
[Range]	$32 \le n \le 127$						
[Description]	Cancels user-defined characters.						
[Details]	<ul> <li>This command cancels the pattern defined for the character code specified by <i>n</i>. After the user-defined characters is canceled, the corresponding pattern for the internal character is printed.</li> <li>If a user-defined character has not been defined for the specified character code, the printer ignores this command.</li> </ul>						
[Reference]	ESC &, ESC	<b>\$%</b>					

# 20. ESC @

[Name]	Initialize printer						
[Format]	ASCII	ESC	@				
	Hex	1B	40				
	Decimal	27	64				
[Description]	Clears the was in effe	Clears the data in the print buffer and resets the printer mode to the mode that was in effect when power on					
[Details]	<ul> <li>was in effect when power on.</li> <li>The DIP switch settings are not checked again.</li> <li>The data in the receive buffer is not cleared.</li> <li>The macro definition is not cleared.</li> <li>The NV bit image data is not cleared.</li> <li>The data of the user NV memory is not cleared.</li> </ul>						

# 21. ESC D n1...nk NUL

[Name]	Set horizontal tab positions								
[Format]	ASCII	ESC	D	n1nk	NUL				
	Hex	1B	44	n1nk	00				
	Decimal	27	68	n1nk	0				
[Range] $1 \le n \le 255$									
	$0 \le k \le 32$								
[Description]	Sets horizo	ontal tab p	ositions.						
	<ul> <li><i>n</i> specifies the column number for setting a horizontal tab position from the beginning of the line.</li> <li><i>k</i> indicates the total number of horizontal tab positions to be set.</li> </ul>								
[Details]	• The hor measure right-side	izontal ta d from the e charact	o position e beginni er spac	n is stored as ing of the line ing, and do	s a value of [character width $\times$ n] e. The character width includes the uble-width characters are set with				
	twice the width of normal characters.								

	<ul> <li>This command cancels the previous horizontal tab settings.</li> </ul>
	• When setting $n = 8$ , the print position is moved to column 9 by sending <b>HT</b> .
	• Up to 32 tab positions ( <i>k</i> = 32) can be set. Data exceeding 32 tab positions is processed as normal data.
	<ul> <li>Transmit [n] k in ascending order and place a NUL code 0 at the end.</li> </ul>
	• When [n] k is less than or equal to the preceding value [n] k-1, tab setting is finished and the following data is processed as normal data.
	ESC D NUL cancels all horizontal tab positions.
	• The previously specified horizontal tab positions do not change, even if the character width changes.
	<ul> <li>The character width is memorized for each standard and page mode.</li> </ul>
[Default]	The default tab positions are at intervals of 8 characters (columns 9, 17, 25,) for font A (12 $\times$ 24).
[Reference]	НТ

# 22. ESC E n

<u> 22. L3C L II</u>									
[Name]	Turn emph	Turn emphasized mode on/off							
[Format]	ASCII	ESC	Е	n					
	Hex	1B	45	n					
	Decimal	27	69	n					
[Range]	0 🗆 🗆 n 🗆	255							
[Description] Turns emphasized mode on or off									
	<ul> <li>When the LSB of n is 0, emphasized mode is turned off</li> </ul>								
	<ul> <li>U When the LSB of n is 1, emphasized mode is turned on.</li> </ul>								
[Details]	• 🗆 Only t	he least s	ignifica	nt bit o	n is enabled.				
	<ul> <li>This command and ESC ! turn on and off emphasized mode in the same way.</li> </ul>								
	Be careful when this command is used with ESC !.								
[Default]	n = 0								
[Reference]	ESC !								

# 23. ESC G n

	<u>23. LOC</u>							
[Format]ASCIIESCG $n$ Hex1B47 $n$ Decimal2771 $n$ [Range] $0 \le n \le 255$ $1 \le n \le 255$ [Description]Turns double-strike mode on or off. • When the LSB of $n \ge 0$ , double-strike mode is turned off. • When the LSB of $n \ge 1$ , double-strike mode is turned on.	[Name]	Turn on/o	Turn on/off double-strike mode					
Hex1B47nDecimal2771n[Range] $0 \le n \le 255$ $0 \le n \le 255$ [Description]Turns double-strike mode on or off. • When the LSB of $n$ is 0, double-strike mode is turned off. • When the LSB of $n$ is 1, double-strike mode is turned on.	[Format]	ASCII	ESC	G	n			
Decimal2771 $n$ [Range] $0 \le n \le 255$ [Description]Turns double-strike mode on or off. • When the LSB of $n$ is 0, double-strike mode is turned off. • When the LSB of $n$ is 1, double-strike mode is turned on.		Hex	1B	47	n			
[Range] $0 \le n \le 255$ [Description]Turns double-strike mode on or off.• When the LSB of $n$ is 0, double-strike mode is turned off.• When the LSB of $n$ is 1, double-strike mode is turned on.		Decimal	27	71	n			
<ul> <li>[Description] Turns double-strike mode on or off.</li> <li>When the LSB of <i>n</i> is 0, double-strike mode is turned off.</li> <li>When the LSB of <i>n</i> is 1, double-strike mode is turned on.</li> </ul>	[Range]	$0 \le n \le 25$	5					
	[Description]	<ul> <li>Turns double-strike mode on or off.</li> <li>When the LSB of <i>n</i> is 0, double-strike mode is turned off.</li> <li>When the LSB of <i>n</i> is 1, double-strike mode is turned on</li> </ul>						
<ul><li>[Details]</li><li>Only the lowest bit of <i>n</i> is enabled.</li><li>Printer output is the same in double-strike mode and in emphasized mode.</li></ul>	[Details]	<ul> <li>Only the lowest bit of <i>n</i> is enabled.</li> <li>Printer output is the same in double-strike mode and in emphasized mode.</li> </ul>						
[Default]   n = 0	[Default]	<i>n</i> = 0						
[Reference] ESC E	[Reference]	ESC E						

# 24. ESC J n

[Name]	Print and fe	ed paper								
[Format]	ASCII	ESC	J	n						
	Hex	1B	4A	n						
	Decimal	27	74	n						
[Range]	0 ≤ <i>n</i> ≤ 255									
[Description]	Prints the data in the print buffer and feeds the paper [ $n \times$ vertical or horizontal motion unit] inches.									
[Details] • After printing is completed, this command sets the print starting positive beginning of the line.										
	• The paper feed amount set by this command does not affect the values set by ESC 2 or ESC 3.									
	<ul> <li>The horizontal and vertical motion unit are specified by GS P.</li> </ul>									
	<ul> <li>The GS P command can change the vertical (and horizontal) motion unit. However, the value cannot be less than the minimum vertical movement amount, and it must be in even units of the minimum vertical movement amount.</li> </ul>									
	<ul> <li>In standard mode, the printer uses the vertical motion unit (y).</li> </ul>									
	<ul> <li>In page mode, this command functions as follows, depending on the starting position of the printable area:</li> </ul>									
	① When the starting position is set to the upper left or lower right of the printable area using ESC T, the vertical motion unit (v) is used.									
	② When the starting position is set to the upper right or lower left of the print able area using ESC T, the horizontal motion unit (x) is used.									
	• The maximum line spacing is 956mm. When the setting value exceeds the									

 The maximum line spacing is 956mm. When the setting value exceeds the maximum, it is converted to the maximum automatically.

[Reference]

GS P

# 25. ESC L

<u>ZJ. LJC L</u>									
[Name]	Select pa	ge mode	;						
[Format]	ASCII	ESC	L						
	Hex	1B	4C						
	Decimal	27	76						
[Description]	Switches	Switches from normal mode to page mode.							
[Details]	<ul> <li>This command is enabled only when processed at the beginning of a line in standard mode.</li> </ul>								
	<ul> <li>This command has no effect in page mode.</li> </ul>								
	<ul> <li>After printing by FF is completed or by using ESC S, the printer returns to standard mode.</li> </ul>								
	<ul> <li>This command sets the position where data is buffered to the position specified by ESC T within the printing area defined by ESC W.</li> </ul>								
	This command switches the settings for the following commands (in which the								
	values can be set independently in standard mode and page mode) to those for page mode:								
	① Set	right-sid	de char	acter spacing: ESC SP, FS S					
	② Select default line spacing: ESC 2, ESC 3								
	<ul> <li>Only valve settings is possible for the following commands in page mode; these commands are not executed.</li> </ul>								
	1 Turn 90° clockwise rotation mode on/off: ESC V								

②□ Select justification: ESC a

- $\bigcirc$  Turn upsidedown printing mode on/off: ESC {
- (4) Set left margin: **GS L**
- $\textcircled{5}\square$  Set printable area width: GS W
- The following command is ignored in page mode:
  - $\textcircled{1}\square$  Execute test print:GS ( A
- The following command is not available in page mode:
  - $\textcircled{1}\square$  Print NV bit image: FS p
  - ② Define NV bit image: FS q
  - ③ Write to user NV memory: FS g 1
  - (4)  $\square$  Print raster bit image: **GS v 0**
- The printer returns to standard mode when power is turned on, the printer is reset, or **ESC** @ is used.

[Reference] FF, CAN, ESC FF, ESC S, ESC T, ESC W, GS \$, GS \

## <u>26. ESC M n (\*)</u>

[Name]	Select	Select character font							
[Format]	ASCII		ESC	Μ	n				
	Hex		1B	4D	n				
	Decim	al	27	77	n				
[Range]	n = 0, 1, 48, 49								
[Description]	Description] Selects character fonts.								
	n	Function							
	0,48	Charac	cter font	A (12 × 2	24) sel	ected.			
	1,49	Character font B (9 $\times$ 17) selected.							

## 27. ESC R n

[Name]	Select an international character set					
[Format]	ASCII	ESC	R	n		
	Hex	1B	52	n		
	Decimal	27	82	n		
[Range]	0 ≤ <i>n</i> ≤ 15					

[Description] Selects an international character set *n* from the following table:

n	Character
0	U.S.A.
1	France
2	Germany
3	U.K.

4	Denmark I			
5	Sweden			
6	Italy			
7	Spain I			
8	Japan			
9	Norway			
10	Denmark II			
11	Spain II			
12	Latin			
13	Korea			
14	Slovenia/Croatia			
15	Chinese			

[Default] n = 0

# <u>28. ESC S (\*)</u>

[Name]	Select stan	dard mod	Э						
[Format]	ASCII	ESC	S						
	Hex	1B	53						
	Decimal	27	83						
[Description]	Switches fr	om page r	node to stan	dard mode.					
[Details]	<ul> <li>This con</li> </ul>	nmand is e	effective only	in page mode.					
	<ul> <li>Data buffered in page mode are cleared.</li> </ul>								
	<ul> <li>This command sets the print position to the beginning of the line.</li> </ul>								
	<ul> <li>The printing area set by ESC W are initialized.</li> </ul>								
	<ul> <li>This command switches the settings for the following commands (in which the</li> </ul>								
	values can be set independently in standard mode and page mode) to those for								
	standard mode:								
	① □ Set right-side character spacing: ESC SP, FS S								
	② Selec	② Select default line spacing: ESC 2, ESC 3							
	<ul> <li>The follo</li> </ul>	wing com	mands are e	nabled only to set in standard mode.					
	① Set pr	inting area	a in page mo	de: ESC W					
	② Selec	t print dire	ction in page	e mode: ESC T					
	<ul> <li>The follo</li> </ul>	wing com	mands are ig	nored in standard mode.					
	① Set at	osolute ve	rtical print po	sition in page mode: GS \$					
	② Set re	lative vert	ical print pos	ition in page mode: GS \					
	• Standard mode is selected automatically when power is turned on, the printer is								
	reset, or command ESC @ is used.								
[Reference]	FF, ESC I	F, ESC L							

# <u>29. ESC T n (\*)</u>

[Name]	Select pri	Select print direction in page mode						
[Format]	ASCII	ESC	Т	n				
	Hex	1B	54	n				
	Decimal	27	84	n				

	n	Print Direction	Starting Position					
	n specifies	starting position as follow	s:					
[Description]	Selects the print direction and starting position in page mode.							
	$48 \le n \le 51$							
[Range]	$0 \le n \le 3$							

Left to right

Right to left

Bottom to top

Top to bottom

0,48

1,49

2, 50

3, 51

A				D	
				Ļ	
				Ļ	ħ
1	Print	area		Ļ	ard
t				t	Forw
t					
t					
В			· · · · ·	-с	

#### [Details]

• When the command is input in standard mode, the printer executes only internal flag operation. This command does not affect printing in standard mode.

Upper left

Lower left

Lower right

Upper right

- This command sets the position where data is buffered within the printing area set by **ESC W**.
- Parameters for horizontal or vertical motion units (x or y) differ as follows, depending on the starting position of the printing area:
  - If the starting position is the upper left or lower right of the printing area, data is buffered in the direction perpendicular to the paper feed direction: Commands using horizontal motion units: ESC SP, ESC \$, ESC \ Commands using vertical motion units: ESC 3, ESC J, GS \$, GS \
  - If the starting position is the upper right or lower left of the printing area, data is buffered in the paper feed direction:
     Commands using horizontal motion units: ESC 3, ESC J, GS \$, GS \
     Commands using vertical motion units: ESC SP, ESC \$, ESC \

[Default] n = 0

[Reference] ESC \$, ESC L, ESC W, ESC \, GS \$, GS P, GS \

## 30. ESC V n

[Name]	Turn 90° clo	ockwise rotation mode on/off				
[Format]	ASCII	ESC	V	n		
	Hex	1B	56	n		
	Decimal	27	86	n		

[Range]	$0 \le n \le 1, 48 \le n \le 49$							
[Description]	cription] Turns 90° clockwise rotation mode on/off							
	n is used a	as follows:						
	n	Function						
	0, 48	Turns off 90° clockwise rotation mode						
	1, 49	Turns on 90° clockwise rotation mode						
[Details]	This comr	nand affects printing in standard mode. However, the setting is						
	always effective.							
	ullet When underline mode is turned on, the printer does not underline 90°							
	clockwise-	clockwise-rotated.						
	<ul> <li>Double-width and double-height commands in 90° rotation mode enlarge</li> </ul>							
	characters	cters in the opposite directions from double-height and double- width						
	commands	s in normal mode.						
[Default]	n = 0							
[Reference]	ESC !, ESC	>-						

# <u>31. ESC W xL xH yL yH dxL dxH dyL dyH (\*)</u>

[Name]	Set printing	area in p	age mod	е							
[Format]	ASC II	ESC	W	⟨L xŀ	l yL	уH	dxL	dxH	dyL	dyH	
	Hex	1B	57	⟨L xŀ	l yL	уH	dxL	dxH	dyL	dyH	
	Decimal	27	87 xL	xH	yL y	/H c	dxL d	lxH c	dyL d	dyH	
[Range]	$0 \leq xL, xH,$	$0 \le xL$ , xH, yL, yH, dxL, dxH, dyL, dyH $\le 255$ (except dxL= dxH=0 or dyL= dyH=0)									
[Description]	• The horiz and print Each set x0 = [( xl y0 = [( yl dx = [ dx dy = [ dy The print	<ul> <li>The horizontal starting position, vertical starting position, printing area width, and printing area height are defined as x0, y0, dx (inch), dy (inch), respectively. Each setting for the printing area is calculated as follows:</li> <li>x0 = [(xL + xH × 256) × (horizontal motion unit)]</li> <li>y0 = [(yL + yH × 256) × (vertical motion unit)]</li> <li>dx = [dxL + dxH × 256] × (horizontal motion unit)]</li> <li>dy = [dyL + dyH × 256] × (vertical motion unit)]</li> <li>The printing area is set as shown in the figure below.</li> </ul>									
[Details]	<ul> <li>If this conflag oper</li> <li>If the horis printer standata.</li> <li>If the print processi</li> <li>This comby ESC</li> <li>If (horizon the print horizonta)</li> <li>If (vertica) the print starting procession of the print starting procession.</li> </ul>	ommand is ration. Thi zontal or tops comm ting area ng and pr mand sets <b>T</b> within the ntal starting al starting I starting ng area h position).	s input in s comma vertical s nand pro width or ocesses s the pos the printin ng position yidth is a position eight is a	standar and does tarting p cessing height is the follow ition whe g area. n + print utomatic + printing automatic	d mode, not affe osition i and pro set to 0 wing dat ere data ally set ally set	, the pri ect prir s set c cesses ), the p ta as n is buf a width to (hor eight) ( to (ve	rinter ex nting in outside t s the fol orinter s formal c fered to ) exceed izontal exceed rtical pr	xecutes standar the prin llowing tops co data. the po eds the printabl s the pr intable	only in rd mode table a data as mmand sition s printab e area intable area -	aternal e. rea, the s normal d pecified le area, - area, vertical	

- The horizontal and vertical motion unit are specified by **GS P**. Changing the horizontal or vertical motion unit does not affect the current printing area.
- The **GS P** command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of minimum horizontal movement amount.
- Use the horizontal motion unit ( x) for setting the horizontal starting position and printing area width, and use the vertical motion unit ( y) for setting the vertical starting position and printing area height.
- When the horizontal starting position, vertical starting position, printing area width, and printing area height are defined as X, Y, Dx, and Dy respectively, the printing area is set as shown in the figure below.



• This printable area for this printer is approximately 73 mm in the horizontal direction and approximately 150mm in the vertical direction.

[Default]

xL = xH = yL = yH = 0dxL = 72, dxH = 2, dyL = 176, dyH = 4

[Reference] CAN, ESC L, ESC T, GS P

# 32. ESC \ nL nH

[Name]	Set relative print position								
[Format]	ASCII	ESC	١	nL	nH				
	Hex	1B	5C	nL	nH				
	Decimal	27	92	nL	nH				
[Range]	$0 \le nL \le 255$								
	$0 \le nH \le 255$								
[Description]	Sets the print starting position based on the current position by using the horizontal or vertical motion unit. • This command sets the distance from the current position to [( $nL + nH \times 256$ ) × horizontal or vertical motion unit]								
[Details]	• Any setting that exceeds the printable area is ignored. • When pitch N is specified to the right: $nL+nH \ge 256 = N$								

When pitch N is specified to the left (the negative direction), use the complement of 65536. When pitch N is specified to the left:

 $nL+nH \times 256 = 65536 - N$ 

- The print starting position moves from the current position to [ N  $\times\square$  horizontal or vertical motion unit]
- The horizontal and vertical motion unit are specified by GS P.
- The **GS P** command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of the minimum horizontal movement amount.
- In standard mode, the horizontal motion unit is used.
- In page mode, the horizontal or vertical motion unit differs as follows, depending on the starting point of the printing area:
  - (1)When the starting position is set to the upper left or lower right of the printable area using **ESC T**, the horizontal motion unit (x) is used.
  - 2When the starting position is set to the upper right or lower left of the

printable area using ESC T, the vertical motion unit (y) is used.

[Reference] ESC \$, GS P

# <u>33. ESC a n</u>

[Name]	Select	justification								_
[Format]	ASCII	ESC	а	n						
	Hex	1B	61	n						
	Decima	l 27	97	n						
[Range]	$0 \le n \le$	2, $48 \le n \le$	n ≤ 50							
[Description]	Aligns a	all the data	in one lin	e to the	specifie	ed posi	tion			
	n selec	n selects the justification as follows:								
	n	n Justification								
	0,48	B Left j	Left justification							
	1, 4	9 Cent	Centering							
	2, 5	0 Right	t justificat	ion						
[Details]	• The c	• The command is enabled only when processed at the beginning of the line in								
	stanc	standard mode.								
	<ul> <li>If this</li> </ul>	command i	s input in	page m	ode, th	e printe	er perfori	ms only i	nternal flag	
	opera	ations.								
	<ul> <li>This c</li> </ul>	<ul> <li>This command executes justification in the printing area.</li> </ul>								
	<ul> <li>This c</li> </ul>	command ju	stifies the	e space	area ac	cordin	g to <b>HT</b> ,	<b>ESC \$</b> 0	r <b>ESC \</b> .	
[Default]	n = 0									
[Example]										
Left justif	ication	(	Centering Right justification				ation			
ABC ABCD			ABC ABCD					ABC ABCD		

# <u>34. ESC c 3 n</u>

ABCDE

[Name]	Select paper	sensor(	(s) to	outp	ut paper end signals
[Format]	ASCII	ESC	С	3	n
	Hex	1B	63	33	n

ABCDE

ABCDE

## Decimal 27 99 51 n

[Range]

[Description] Selects the paper sensor(s) to output paper end signals

• Each bit of *n* is used as follows:

 $0 \leq n \leq 255$ 

Bit	Off/On	Hex	Decimal	Function			
0	Off 00 0		0	Paper roll near-end sensor disabled			
0	On	01	1	Paper roll near-end sensor enabled			
1	Off	00	0	Paper roll end sensor disabled			
1	On	02	2	Paper roll near-end sensor enabled			
2	Off	00 0		Paper roll end sensor disabled			
2	On	04	4	Paper roll near-end sensor enabled			
2	Off	00	0	Paper roll end sensor disabled			
3	On	08	8	Paper roll near-end sensor enabled			
4-7	-	-	-	Undefined			

#### [Note]

- It is possible to select multiple sensors to output signals. Then, if any of the sensors detects a paper end, the paper end signal is output.
  - The command is available only with a parallel interface and is ignored with a serial interface.
  - Sensor is switched when executing this command. The paper end signal switching be delayed depending on the receive buffer state.
  - If either bit 0 or bit 1 is on, the paper roll near-end sensor is selected as the paper sensor outputting paper-end signals
  - If either bit 2 or bit 3 is on, the paper roll end sensor is selected as the paper sensor outputting paper-end signals.
  - When all the sensors are disabled, the paper end signal always outputs a paper present status.
- [Default] n = 0

## 35. ESC c 4 n

[Name]	Select paper sensor(s) to stop printing									
[Format]	ASCII	ESC	С	4	n					
	Hex	1B	63	34	n					
	Decim	al 27	99	52	n					
[Range]	0 ≤ <i>n</i> ≤	0 ≤ <i>n</i> ≤255								
[Description]	Selects the paper sensor(s) used to output paper short singnal.									
	using	<i>n</i> as follow	vs:							
	Bit	Off/On	Hex	Dec	imal	Function				
		Off	00	0		Paper roll near-end sensor disabled				
	0	On	01	1		Paper roll near-end sensor enabled				
		Off	00	0		Paper roll near-end sensor disabled				
	1	On	02	2		Paper roll near-end sensor enabled				

2-7	Undefined
-----	-----------

[Details]

• When one paper sensor is enabled with this command, printing is stopped only when the corresponding paper is selected for printing.

- When a paper-end is detected by the paper roll sensor, the printer goes offline after printing stops.
- When either bit 0 or 1 is on, the printer selects the paper roll near-end sensor for the paper sensor to stop printing.

[Default] n = 0

### 36. ESC c 5 n

[Name]	Enable/disable panel buttons					
[Format]	ASCII	ESC	С	5	n	
	Hex	1B	63	35	n	
	Decimal	27	99	53	n	
[Range]	0 ≤ <i>n</i> ≤ 255					
[Description]	<ul> <li>Enables or disables the panel buttons.</li> <li>When the LSB of n is 0, the panel buttons are enabled.</li> <li>When the LSB of n is 1, the panel buttons are disabled.</li> </ul>					
[Details]	<ul> <li>When the LSB of <i>n</i> is 1, the panel buttons are disabled.</li> <li>Only the lowest bit of n is valid.</li> <li>When the panel buttons are disabled, none of them are usable when the printer cover is closed.</li> <li>In this printer, the panel buttons are the FEED button.</li> <li>In the macro ready mode, the FEED button are enabled regardless of the settings of this command; however, the paper cannot be fed by using these buttons.</li> </ul>					
[Default]	<i>n</i> = 0					

## 37. ESC d n

[Name]	Print and fe	ed <i>n</i> lines		
[Format]	ASCII	ESC	d	n
	Hex	1B	64	n
	Decimal	27	100	n
[Range]	$0 \le n \le 255$			
[Description] [Details]	<ul> <li>0 ≤ n ≤ 255</li> <li>Prints the data in the print buffer and feeds n lines.</li> <li>This command sets the print starting position to the beginning of the line.</li> <li>This command does not affect the line spacing set by ESC 2 or ESC 3.</li> <li>The maximum paper feed amount is 1016 mm (40 inches). If the paper feed amount (<i>nx</i> line spacing) of more than 1016 mm (40 inches) is specified, the printer feeds the paper only 1016 mm (40 inches).</li> </ul>			
[Reference]	ESC 2, ESC	3		

# 38. ESC p m t1 t2

[Name]	Generate	Generate pulse				
[Format]	ASCII	ESC	ESC p <i>m t1 t</i> 2			
	Hex	1B	70	т	t1	ť2
	Decimal	27	112	т	t1	t2
[Range]	<i>m</i> = 0, 1,	48, 49				
	$0 \le t1 \le 2$	55, 0≤ <i>t</i> 2 ≤	255			
[Description]	Outputs t	he pulse sp	pecified b	y t1 a	and	t2 to connector pin m as follows:
	m	Connec	Connector pin			
	0, 48	Drawer I	Drawer kick-out connector pin 2.			
	1, 49	Drawer I	Drawer kick-out connector pin 5.			
[Details]	• The pulse ON time is [ $t1 \times 2$ ms] and the OFF time is [ $t2 \times 2$ ms].					
	• If $t^2 < t^1$ , the OFF time is [ $t^1x^2$ ms]					
[Reference]	DLE DC4	1				

# 39. ESC t n

[Name]	Select cha	aracter	code ta	ble
[Format]	ASCII	ESC	t	n
	Hex	1B	74	n
	Decimal	27	116	n
[Range]	0 ≤ <i>n</i> ≤10, 1	6 ≤ n <u>≤</u>	≦19	
[Description]	Selects a pa	age <i>n</i> f	rom the	character code table.
	n		Page	
	0		PC437	[U.S.A.Standard Europe]
	1		Kataka	na
	2		PC850	:Multilingual
	3		PC860	:Portuguese
	4		PC863	[Canadian French]
	5		PC865	:Nodic
	6		West E	urope
	7		Greek	
	8		Hebrev	v
	9		PC755	:East Europe
	10		Iran	
	16		WPC12	252
	17		PC866	:Cyrillic#2
	18		PC852	:Latin2
	19		PC858	
	20		IranII	
	21		Latvian	1

[Default] n = 0

		^	
n	_	()	
	_	• •	

# 40. ESC { n

[Name]	Turns on/o	off upsid	de-dov	vn printing mode					
[Format]	ASCII	ESC	{	n					
	Hex	1B	7B	n					
	Decimal	27	123	n					
[Range]	$0 \le n \le 25$	55							
[Description]	Turns ups	side-do	wn prii	nting mode on or	r off.				
	<ul> <li>When the</li> </ul>	<ul> <li>When the LSB of n is 0, upside-down printing mode is turned off.</li> </ul>							
	<ul> <li>When the</li> </ul>	ne LSB	of n is	1, upside-down	printing mode is turned on.				
[Details]	<ul> <li>Only the second s</li></ul>	<ul> <li>Only the lowest bit of n is valid.</li> </ul>							
	<ul> <li>This cor standar</li> </ul>	<ul> <li>This command is enabled only when processed at the beginning of a line in standard mode.</li> </ul>							
	<ul> <li>When the flag operation</li> </ul>	<ul> <li>When this command is input in page mode, the printer performs only internal flag operations.</li> </ul>							
	This cor	<ul> <li>This command does not affect printing in page mode.</li> </ul>							
	<ul> <li>In upsid and the</li> </ul>	e-down en prints	i printii s it.	ng mode, the pri	nter rotates the line to be printed by 180°				
[Default]	n = 0								
[Example]									
	$\sim$	$\overline{\mathbf{w}}$	ഹ	7	frank				
	ABCD	EF		•	V B C D E L				



# 41. FS p n m

[Name]	Print NV	Print NV bit image					
[Format]	ASCII	FS	р	n	т		
	Hex	1C	70	n	т		
	Decimal	28	112	n	т		
[Range]	$1 \le n \le 2$	55					
	$0 \le m \le 3$	3 , 48 ≤ <i>m</i>	≤51				
[Description]	Prints a N	IV bit imag	ge <i>n</i> us	sing	the mode specified b	ру <i>т</i> .	
	m	Mode		Ve	ertical Dot Density		
						Horizontal Dot Density	
	0, 48	Normal		20	00 dpi	200 dpi	
	1, 49	Double-	width	20	)0 dpi	100 dpi	
	2, 50	Double-l	neight	10	)0 dpi	200 dpi	
	3, 51	Quadrup	le	10	00 dpi	100 dpi	

[dpi: dots per 25.4 mm {1"}]

- *n* is the number of the NV bit image (defined using the **FS q** command).
- *m* specifies the bit image mode.

[Details]

- NV bit image means a bit image which is defined in a non-volatile memory by **FS q** and printed by **FS p**.
  - This command is not effective when the specified NV bit image has not been defined.
  - In standard mode, this command is effective only when there is no data in the print buffer.
- In page mode, this command is not effective.
  - This command is not affected by print modes (emphasized, double-strike, underline,character size, white/black reverse printing, or 90° rotated characters, etc.), except upside-down printing mode.
  - If the printing area width set by GS L and GS W for the NV bit image is less than one vertical line, the following processing is performed only on the line in question. However, in NV bit image mode, one vertical line means 1 dot in normal mode (*m*=0, 48) and in double-height mode (*m*=2, 50), and it means 2 dots in double-width mode (*m*=1, 49) and in quadruple mode(*m*=3, 51).

①The printing area width is extended to the right in NV bit image mode up to one line vertically. In this case, printing does not exceed the printable area.

②If the printing area width cannot be extended by one line vertically, the left margin is reduced to accommodate one line vertically.

• If the downloaded bit-image to be printed exceeds one line, the excess data is not printed.

- This command feeds dots (for the height *n* of the NV bit-image) in normal and double-widthmodes, and (for the height *n* · 2 of the NV bit-image) in double-height and quadruple modes, regardless of the line spacing specified by ESC 2 or ESC 3.
- After printing the bit image, this command sets the print position to the beginning of the lineand processes the data that follows as normal data.

[References] ESC , FS q, GS /, GS v 0

#### 42. FS q n [xL xH yL yH d1...dk]1...[xL xH yL yH d1...dk]n

[Name]	Define NV	bit in	nage		
[Format]	ASCII	FS	q	n	[xL xH yL yH d1dk]1[ xL xH yL yH d1dk]n
	Hex	1C	71	n	[xL xH yL yH d1dk]1[ xL xH yL yH d1dk]n
	Decimal	28	113	n	[xL xH yL yH d1dk]1[ xL xH yL yH d1dk]n
[Range]	$1 \le n \le 255$				
	$0 \le xL \le 255$	5			
	1 ≤ ( xL + xł	H × 2	56) ≤	102	23
	1 ≤ ( yL + ył	H × 2	56) ≤	288	3
	0 ≤ d ≤ 255				
	k = ( xL + xł	<b>H x</b> 2	56) ×	(yL	. + yH × 256) × 8
	Total define	d dat	a area	ι = C	).5M bits (64K bytes)
[Description]	Define the N	V bit	imag	e sp	ecified by <i>n</i> .

- *n* specifies the number of the defined NV bit image.
  - *xL*, *xH* specifies (*xL* + *xH*  $\times$  256)  $\times$  8 dots in the horizontal direction for the NV bit image you are defining.
  - *yL*, *yH* specifies (*yL* + *yH*  $\times$ 256)  $\times$  8 dots in the vertical direction for the NV bit image you are defining.

[Details]

• This command cancels all NV bit images that have already been defined by this command. The printer can not redefine only one of several data definitions previously defined. In this case, all data needs to be sent again.

• From the beginning of the processing of this command till the finish of hardware reset, mechanical operations (including initializing the position of the printer head when the cover is open, paper feeding by using the FEED button, etc.) cannot be performed.

• During processing this command, the printer is in BUSY when writing the data to the NV user memory and stops receiving data. Therefore it is prohibitted to transmit the data including the real-time commands during the execution of this command.

- NV bit image means a bit image which is defined in a non-volatile memory by FS q and printed by FS p.
- In standard mode, this command is effective only when processed at the beginning of the line.
- In page mode, this command is not effective.
  - This command is effective when 7 bytes <FS<yH> is processed as a normal value.
    When the amount of data exceeds the capacity left in the range defined by *xL*, *xH*.
  - *yL, yH*, the printer processes *xL, xH, yL, yH* out of the defined range.
  - In the first group of NV bit images, when any of the parameters *xL*, *xH*, *yL*, *yH* is out of the definition range, this command is disabled.
  - In groups of NV bit images other than the first one, when the printer processes *xL*, *xH*, *yL*, *yH* out of the defined range, it stops processing this command and starts writing into the NV images. At this time, NV bit images that haven<sub>i</sub><sup>-</sup> t been defined are disabled (undefined), but any NV bit images before that are enabled.
  - The *d* indicates the definition data. In data (*d*) a 1 bit specifies a dot to be printed and a 0 bit specifies a dot not to be printed.
  - This command defines *n* as the number of a NV bit image. Numbers rise in order from NV bit image 01H. Therefore, the first data group [*xL xH yL yH d1...dk*] is NV bit image 01H, and the last data group [*xL xH yL yH d1...dk*] is NV bit image *n*. The total agrees with the number of NV bit images specified by command FS p.
  - A definition data of a NV bit image consists of [xL xH yL yH d1...dk]. Therefore, when only one NV bit image is defined n=1, the printer processes a data group [xL xH yL yH d1...dk] once. The printer uses ([data: (xL + xH×256) ×(yL + yH×256) ×8] + [header :4])bytes of NV memory.
  - The definition area in this printer is a maximum of 0.5M bits (64K bytes). This command can define several NV bit images, but cannot define a bit image data whose total capacity [bit image data + header] exceeds 0.5M bits (64K bytes).
- The printer is busy immediately before writing into NV memory.
  - The printer does not transmit ASB status and perform status detection during processing of this command even when ASB is specified.

- When this command is received during macro definition, the printer ends macro definition, and begins performing this command.
- Once a NV bit image is defined, it is not erased by performing **ESC** @, reset, and power off.
- This command performs only definition of a NV bit image and does not perform printing.Printing of the NV bit image is performed by the **FS p** command.

[Details]

- Frequent write command execution may cause damage the NV memory. Therefore, it is recommended to write the NV memory 10 times or less a day.
- The printer performs a hardware reset after the procedure to place the image into the NV memory. Therefore, user-defined characters, downloaded bit images, and macros should be defined only after completing this command. The printer clears the receive and print buffers and resets the mode to the mode that was in effect at power on. At this time, DIP switch settings are checked again.

#### [Reference] FS p

[Example] When xL = 64, xH = 0, yL = 96, yH = 0



### 43. GS!n

[Name]	Select character size					
[Format]	ASCII	GS	!	n		
	Hex	1D	21	n		
	Decimal	29	33	n		
[Range]	$0 \le n \le 25$	5				

 $(1 \le vertical number of times \le 8, 1 \le horizontal number of times \le 8)$ 

[Description] Selects the character height using bits 0 to 2 and selects the character width using

## bits 4 to 7, as follows:

Bit	Off/On	Нех	Decimal	Function			
0.2	Character	haight coloctic	n See Teble 2				
0~3	Character	Character height selection. See Table 2.					
4~7	Character	Character width selection. See Table 1.					

#### Table 1 Table 2

#### **Character Width Selection**

Hex	Decimal	Width
00	0	1(normal)
10	16	2(double-width)
20	32	3
30	48	4
40	64	5
50	80	6
60	96	7
70	112	8

### **Character Height Selection**

Hex	Decimal	Width
00	0	1(normal)
01	1	2(double-height)
02	2	3
03	3	4
04	4	5
05	5	6
06	6	7
07	7	8

[Details]

 This command is all characters (alphanumeric and Kanji) effective except for HRI characters.

- If n is outside of the defined range, this command is ignored.
- In standard mode, the vertical direction is the paper feed direction, and the horizontal direction is perpendicular to the paper feed direction. However, when character orientation changes in 90° clockwise-rotation mode, the relationship between vertical and horizontal directions is reversed.

- In page mode, vertical and horizontal directions are based on the character orientation.
- When characters are enlarged with different sizes on one line, all the characters on the line are aligned at the baseline.
- The **ESC** ! command can also turn double-width and double-height modes on or off. However, the setting of the last received command is effective.

[Default] n = 0

[Reference] ESC !

#### 44. GS \$ nL nH

[Name]	Set absolute vertical print position in page mode							
[Format]	ASCII	GS	\$	nL	nH			
	Hex	1D	24	nL	nH			
	Decimal	29	36	nL	nH			
[Range]	$0 \le nL \le 2$	55, 0 ≤	≤ nH :	≤ 255				
[Description] • Sets the absolute vertical print starting position for buffer character data in page mode.								
<ul> <li>This command sets the absolute print position to [( nL + nH × 256) × (vertical or horizontal motion unit)] inches.</li> </ul>								
<ul> <li>[Details] • This command is effective only in page mode.</li> <li>• If the [( nL + nH × 256) × (vertical or horizontal motion unit)] exceeds the</li> </ul>								

- specified printing area, this command is ignored.
- The horizontal starting buffer position does not move.
- The reference starting position is that specified by ESC T.
- This command operates as follows, depending on the starting position of the printing area specified by **ESC T**:
  - ①When the starting position is set to the upper left or lower right, this command sets the absolute position in the horizontal direction.
  - ②When the starting position is set to the upper right or lower left, this command sets the absolute position in the vertical direction.
- The horizontal and vertical motion unit are specified by GS P.

[Reference] ESC \$, ESC T, ESC W, ESC \, GS P, GS \

[Name]	Define downloaded bit image					
[Format]	ASCII	GS	*	x	У	d1d(x $ imes$ y $ imes$ 8)
	Hex	1D	2A	x	У	d1d(x $ imes$ y $ imes$ 8)
	Decimal	29	42	x	У	d1d(x $ imes$ y $ imes$ 8)
[Range]	$1 \le x \le 255$					
	$1 \le y \le 48$					
	<i>x</i> ≤ <i>y</i> ≤912					
	$0 \le d \le 255$					

## 45. GS \* x y d1...d(x × y × 8)

#### Defines a downloaded bit image using the number of dots specified by x and y [Description] • x specifies the number of dots in the horizontal direction.

• y specifies the number of dots in the vertical direction.

[Details]

- The number of dots in the horizontal direction is  $x \times a$  8 in the vertical direction it is  $y \times 8$ . • If  $x \times 0$  yis out of the specified range, this command is disabled.

  - The d indicates bit-image data. Data (d) specifies a bit printed to 1 and not printed to 0.
  - The downloaded bit image definition is cleared when:
    - ① ESC @ is executed.
    - 2 ESC & is executed.
    - ③ FS q is executed.
    - ④ Printer is reset or the power is off.
  - The following figure shows the relationship between the downloaded bit image and the printed data.



[Reference] GS/

#### 46. GS (A pL pH n m

[Name]	Save printed	hex data							
[Format]	ASCII	GS	(	А	рL	pН	n	m	
	Hex	1D	28	41	рL	рΗ	n	m	
	Decimal	29	40	65	рL	рΗ	n	m	
[Range]	pL=2,pH=0;								
	n=0,48 ;m=1,4	9;							
<u>47. GS/r</u>	47. GS/m								

[Name]	Print dow	Print downloaded bit image					
[Format]	ASCII	GS	/	т			
	Hex	1D	2F	т			

Decimal 29	9 47	т	
$0 \le m \le 3, 48 \le n$	<i>m</i> ≤51		
n] Prints a downloa	aded bit imag	ge using the mode spe	cified by <i>m</i> .
m selects a mod	le from the ta	able below:	
Mode	Vertical D	ot Density (DPI)	Horizontal Dot Density (DPI)
Normal	200		200
Double-width	200		100
Double-height	100		200
Quadruple	100		100
<ul> <li>This command In standard morprint buffer.</li> <li>This command underline, cl mode.</li> <li>If the download excess data is</li> </ul>	nd is ignored ode, this con I has no effe haracter size ded bit-imag not printed.	d if a downloaded bit in mmand is effective only ect in the print modes ( e, or white/black revers e to be printed exceed	hage has not been defined. v when there is no data in the emphasized, double-strike, the printing), except forupsidedownprinting ls the printable area, the
	Decimal29 $0 \le m \le 3, 48 \le n$ a)Prints a downloadm selects a modeModeNormalDouble-widthDouble-heightQuadruple• This command• In standard modeprint buffer.• This command• If the download• If the download• excess data is	Decimal2947 $0 \le m \le 3, 48 \le m \le 51$ $0 \le m \le 3, 48 \le m \le 51$ Prints a downloaded bit image m selects a mode from the tailModeVertical DModeVertical DNormal200Double-width200Double-height100Quadruple100• This command is ignored• In standard mode, this comprint buffer.• This command has no effer underline, character size mode.• If the downloaded bit-image excess data is not printed.	Decimal2947m $0 \le m \le 3, 48 \le m \le 51$ Prints a downloaded bit image using the mode spect m selects a mode from the table below:ModeVertical Dot Density (DPI)Normal200Double-width200Double-height100Quadruple100• This command is ignored if a downloaded bit in • In standard mode, this command is effective only print buffer.• This command has no effect in the print modes ( underline, character size, or white/black reverse mode.• If the downloaded bit-image to be printed exceed excess data is not printed.

[Reference] GS \*

## 48. GS:

[Name]	Start/end	macro	definition				
[Format]	ASCII	GS	:				
	Hex	1D	3A				
	Decimal	29	58				
[Description]	Starts or e	ends ma	acro definition.				
[Details]	Macro	definitio	n starts when this command is received during normal operation.				
	Macro	definitio	on ends when this command is received during macro definition.				
	• When <b>(</b>	<b>3S ^</b> is	received during macro definition, the printer ends macro				
	definiti	on and	clears the definition.				
	<ul> <li>Macro i</li> </ul>	s not de	efined when the power is turned on.				
	• The defined contents of the macro are not cleared by ESC @. Therefore,						
	ESC @ can be included in the contents of the macro definition.						
	• If the printer receives GS : again immediately after previously receiving GS :						
	the printer remains in the macro undefined state.						
	<ul> <li>The contents of the macro can be defined up to 2048 bytes. If the macro</li> </ul>						
	definiti	on exce	ed 2048 bytes, excess data is not stored.				
[Reference]	GS ^						

# <u>49. GSBn</u>

[Name]	Turn whi	te/blac	k rever	se pri	nting mode
[Format]	ASCII	GS	В	n	
	Hex	1D	42	n	
	Decimal	29	66	n	
[Range]	0 ≤ n ≤ 25	55			

[Description] Turns on or off white/black reverse printing mode.

- When the LSB of n is 0, white/black reverse mode is turned off.
- When the LSB of n is 1, white/black reverse mode is turned on.

[Details]

- Only the lowest bit of n is valid.
- This command is available for all characters, except HRI characters.
- When white/black reverse printing mode is on, it also applied to character spacing set by **ESC SP**.
- This command does not affect bit image, user-defined bit image, bar code, HRI characters, and spacing skipped by HT, ESC \$, and ESC \.
- This command does not affect the space between lines.
- White/black reverse mode has a higher priority than underline mode. Even if underline mode is on, it is disabled (but not canceled) when white/black reverse mode is selected.

[Default] n = 0

#### 50. GSH n

[Name]	Select prir	nting po	osition	for HF	I characters
[Format]	ASCII	GS	Н	n	
	Hex	1D	48	n	
	Decimal	29	72	n	
[Range]	$0 \le n \le 3$ ,	48 ≤ n	≤ 51		

[Description] Selects the printing position of HRI characters when printing a bar code.

	n	selects	the	printing	position	as follows:
--	---	---------	-----	----------	----------	-------------

n	Printing position
0, 48	Not printed
1, 49	Above the bar code
2, 50	Below the bar code
3, 51	Both above and below the bar code

• HRI indicates Human Readable Interpretation.

[Details] • HRI characters are printed using the font specified by GS f.

[Default] n = 0

[Reference] GS f, GS k

## 51. GSLnLnH

[Name]	Set left margin						
[Format]	ASCII	GS	L	nL	nH		
	Hex	1D	4C	nL	nH		
	Decimal	29	76	nL	nH		
[Range]	$0 \le nL \le 255$						
	0 ≤ <i>nH</i> ≤ 255						
[Description]	Sets the left margin using nL and nH.						



## 52、GSPxy

[Name]	Set horizo	ontal a	nd ve	ertica	l mo	tion units				
[Format]	ASCII	GS	Р	х	у					
	Hex	1D	50	х	у					
	Decimal	29	80	х	у					
[Range]	$0 \le x \le 25$	5								
	$0 \le y \le 25$	5								
[Description]	Sets the h	orizon	tal an	d ve	rtica	I motion units to approximately 25.4/ x mm { 1/ x $\sim$				
	inches} ar	nd app	roxim	ately	/ 25.	4/ y mm {1/ y inches}, respectively.				
	When x ar	nd y ai	re set	to 0	, the	default setting of each value is used.				
[Details]	• The hori	zontal	direc	tion	is pe	erpendicular to the paper feed direction and the				
	vertical direction is the paper feed direction.									
	• In standa	ard mo	ode, tl	he fo	ollow	ing commands use x or y, regardless of character				
	rotation	(upsic	de-do	wn o	r 90°	° clockwise rotation):				
	①Comm	ands	using	x: E	SC S	SP, ESC \$, ESC  FS S, GS L, GS W				
	②Comm	ands	using	y: E	SC :	3, ESC J, GS V				
	<ul> <li>In page orientation</li> </ul>	mode, ion:	the fo	ollow	/ing (	command use x or y, depending on character				
	①When	the pr	int sta	arting	g pos	sition is set to the upper left or lower right of the				
	printir	ng area	a usir	ng Es	SC T	(data is buffered in the direction perpendicular to				
	the pa	aper fe	ed di	recti	on):					
	Comr	nands	using	g x: E	ESC	SP, ESC \$, ESC W, ESC  FS S				
	Comr	nands	using	, y: <b>I</b>	ESC	3, ESC J, ESC W, GS \$, GS  GS V				
	2 When	the pr	int sta	arting	g pos	sition is set to the upper right or lower left of the				
	printir	ng area	a usir	ng E	SC T	(data is buffered in the paper feed direction):				

	Commands using x: ESC 3, ESC J, ESC W, GS \$, GS \
	Commands using y: ESC SP, ESC \$, ESC W, ESC FS S, GS V
	<ul> <li>The command does not affect the previously specified values.</li> </ul>
	• The calculated result from combining this command with others is truncated to
	the minimum value of the mechanical pitch.
[Default]	x = 200, y = 200, horizontal 1/8mm, vertical 1/7mm。
[Reference]	ESC SP, ESC \$, ESC 3, ESC J, ESC W, ESC  GS \$, GS L, GS V, GS W, GS \

# 53. ①GS V m ②GS V m n

[Name]	Select cut mode and cut paper								
[Format]	1)ASCII	GS	V	т					
	Hex	1D	56	т					
	Decimal	29	86	m					
	2)ASCII	GS	V	т	n				
	Hex	1D	56	т	n				
	Decimal	29	86	т	n				
[Range]	① <i>m=</i> 0, <i>4</i> 8, 1,49								
	≤ n ≤ 255	5							

[Description] Selects a mode for cutting paper and executes paper cutting. The value of m selects the mode as follows:

m	Print mode
0, 48	Full cut
1, 49	Partial cut
66	Feeds paper (cutting position + [ $n \times \Box$ (vertical motion unit)]), and cuts the paperin
	partial

[Note]

- This command is effective only processed at the beginning of a line.
- When m = 0, 48, 1, 49, the printer cut paper directly.
- When *n* = 66, the printer feeds the paper to (cutting position + [*nX* □ vertical motion unit]) and cuts it.
- The horizontal and vertical motion unit are specified by GS P.
- The paper feed amount is calculated using the vertical motion unit (y).

## 54. GS W nL nH

[Name]	Set printing area width								
[Format]	ASCII	GS	W	nL	nH				
	Hex	1D	57	nL	nH				
	Decimal	29	87	nL	nH				
[Range]	$0 \le nL \le 255$								
	0 ≤ <i>nH</i> ≤ 255								

[Description] Sets the printing area width to the area specified by nL and nH.

• The printing area width is set to [(  $nL + nH \times \square 256$ )  $\times \square$  horizontal motion unit]] inches.



[Details]

• This command is effective only processed at the beginning of the line.

• In page mode, the printer performs only internal flag operations.

- This command does not affect printing in page mode.
- If the [left margin + printing area width] exceeds the printable area, [printable area width left margin) is used.
- The horizontal and vertical motion units are specified by **GS P**. Changing the horizontal and vertical motion units does not affect the current left margin.
- The horizontal motion unit (x) is used for calculating the printing area width.

[Default]	nL = 76, nH = 2
[Reference]	GS L, GS P

#### 55. GS\nL nH

[Name]	Set relative	e vertical	print	positio	n in pag	e mode					
[Format]	ASCII	GS	١	nL	nH						
	Hex	1D	5C	nL	nH						
	Decimal	29	92	nL	nH						
[Range]	$0 \le nL \le 25$	55									
	$0 \le nH \le 2$	55									
[Description]	] Sets the re	lative ve	ertical	print st	tarting p	osition from the current position in page mode.					
	• This com	mand se	ets the	e distar	nce from	the current position to [( $nL + nH  imes 256$ )					
	imes vertic	cal or ho	rizont	al moti	on unit]						
[Details]	• This com	nmand is	ignor	ed unl	ess pag	e mode is selected.					
	• When pitch N is specified to the movement downward:										
	$nL + nH \times 256 = N$										
	When pitch N is specified to the movement upward (the negative direction), use the										
	complement of 65536.										
	When pitch N is specified to the movement upward:										
	$nL + nH \times 256 = 65536 - N$										
	<ul> <li>Any setting that exceeds the specified printing area is ignored.</li> </ul>										
	• This command function as follows, depending on the print starting position set by ESC T										
	When the starting position is set to the upper left or lower right of the printing, the vertical										
	motion u	unit ( <i>y</i> ) is	s used								
	When th	e startin	g pos	ition is	set to tl	ne upper right or lower left of the printing area, the					
	horizont	al motio	n unit	( <i>x</i> ) is u	used.						
	The horiz	zontal ar	nd vert	ical m	otion un	it are specified by <b>GS P</b> .					

• The **GS P** command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of the minimum horizontal movement amount.

[Reference] ESC \$, ESC T, ESC W, ESC \, GS \$, GS P

## 56. GS ^ r t m

[Name]	Execute	macro	)									
[Format]	ASCII	GS	۸	r	t	m						
	Hex	1D	5E	r	t	m						
	Decimal	29	94	r	t	m						
[Range]	$0 \le r \le 255$	5										
	$0 \le t \le 255$	5										
	m = 0, 1											
[Descriptio	n] Execute	s a ma	cro.									
	<ul> <li>r spec</li> </ul>	ifies th	e nu	mbe	r of t	times to execute the macro.						
	<ul> <li>t speci</li> </ul>	fies th	e wa	iting	time	e for executing the macro.						
	• m spe	cifies r	nacro	o ex	ecut	ing mode.						
	When	When the LSB of $m = 0$ :										
	t $\times$ 100 ms as the waiting time, macro executes r times.											
	When	the L	SB o	f m =	= 1:							
	After	waiting	g for t	the p	perio	d specified by t $\times$ 100 ms, the PAPER OUT LED indicators						
	blink a	and the	e prir	nter	waits	s for the FEED button to be pressed. After the						
	buttor	n is pre	essec	d, the	e pri	nter executes the macro once. The printer						
	repea	ts the	oper	atior	n for	r times.						
[Details]	• The w	aiting	time	is t⇒	< 100	) ms for every macro execution.						
	<ul> <li>If this</li> </ul>	comma	and i	s red	ceive	ed while a macro is being defined, the macro definition						
	is abc	orted a	nd th	e de	efinit	ion is cleared.						
	<ul> <li>If the r</li> </ul>	nacro	is no	t def	inec	l or if r is 0, nothing is executed.						
	<ul> <li>When</li> </ul>	the ma	acro	is ex	ecu	ted (m = 1), paper always cannot be fed by using the						
	FEED	butto	n.									
[Reference	] <b>GS</b> :											

# 57. GS a n

[Name]	Enable/Dis	able Au	tomatic	: Statu	s Bacl	k (AS	SB)					
[Format]	ASCII	GS	а	n								
	Hex	1D	61	n								
	Decimal	29	97	n								
[Range]	0 ≤ <i>n</i> ≤255											
· · · ·								•.				

[Description] Enables or disables ASB and specifies the status items to include, using n as follows:

Bit Off/On Hex Decimal Status for ASB
---------------------------------------

0	Off	00	0	Drawer kick-out connector pin 3 status
				disabled.
	On	01	1	Drawer kick-out connector pin 3 status
				enabled.
1	-	-	-	Undefined.
2	Off	00	0	Error status disabled.
	On	04	4	Error status enabled.
3	Off	00	0	Paper roll sensor status disabled.
	On	08	8	Paper roll sensor status enabled.
4-7	-	-	-	Undefined.

First bit (printer status) :

Bit	Off/On	Hex	Decimal	Status for ASB
0,1	Off	00	0	Undefined. Default 0
2	On	04	4	Undefined. Default 1
3	Off	00	0	Undefined. Default 0
4	On	10	16	Undefined. Default 1
5	Off	00	0	Undefined. Default 0
6	Off	00	0	Feed paper without pressing on FEED
	On	40	64	Feed paper by pressing FEED
7	Off	00	0	Undefined. Default 0
Seco	nd bit (printer :	status):		
Bit	Off/On	Hex	Decimal	Status for ASB
0-4	Off	00	0	Undefined. Default 0
5	Off	00	0	No unretrievable error
	On	20	32	With unretrievable error
6	Off	00	0	No retrievable error
	On	40	64	With retrievable error
7	Off	00	0	Undefined. Default 0
Third	bit (printer sta	itus):		
Bit	Off/On	Hex	Decimal	Status for ASB
0,1	Off	00	0	Undefined. Default 0
2,3	Off	00	0	Paper enough
	On	0C	12	Paper short
4-7	Off	00	0	Undefined. Default 0。
Fourt	h bit(Paper s	ensor status	s):	
Bit	Off/On	Hex	Decimal	Status for ASB
0,3	-	-	-	Undefined
4-7	Off	00	0	Undefined. Default 0

#### 58. GSfn

[Name]	Select f	Select font for Human Readable Interpretation (HRI) characters					
[Format]	ASCII	GS	f	n			
	Hex	1D	66	n			

Decimal 29 102 n

[Range] *n* = 0, 1, 48, 49

[Description] Selects a font for the HRI characters used when printing a bar code.

*n* selects a font from the following table:

n	Font
0, 48	Font A (12 · 24)
1, 49	Font B (9 · 17)

[Details] . HRI indicates Human Readable Interpretation.

. HRI characters are printed at the position specified by GS H.

[Default] n = 0

[Reference] GSH, GSk

### 59. GShn

[Name]	Select ba	r code	e heigh	nt	
[Format]	ASCII	GS	h	n	
	Hex	1D	68	n	
	Decimal	29	104	n	
[Range]	$1 \le n \le 25$	5			
[Description]	Selects the height of the bar code.				
	n specifie	es the	numb	er of	f dots in the vertical direction.
[Default]	n = 162				
[Reference]	GS k				

# 60. ①GS k m d1...dk NUL②GS k m n d1...dn

[Name]	Print bar co	de							
[Format]	1) ASCII	GS	k	n	1	d1	dk	NUL	
	Hex	1D	6	В	т		d1dk	00	
	Decimal	29	10	)7	т		d1dk	0	
	2 ASCII		GS	k		т	n	d1	dn
	Hex		1D	6B		т	n	d1c	In
	Decima	l	29	107		т	n	d1c	dn
[Range]	(1) <b>□</b> 0 ≤ <i>m</i> ≤	6 ( <i>k</i> an	nd <i>d</i> de	epend	s on	the	bar cod	e system	ו used)
	② <b>□65</b> ≤ <i>m</i>	≤73 (n	and d	deper	nds d	on th	e bar co	ode syste	em used)
[Descripti	[Description] Selects a bar code system and prints the bar code.								
	<i>m</i> selects a bar code system as follows:								

r	n	Barcode type	Number of	Character	Remark
			Characters		
	0	UPC-A	11 ≤ k ≤ 12	0~9	48 ≤ d ≤ 57
	1	UPC-E	E 11≤k≤12 0~9		48 ≤ d ≤ 57
	2	JAN13	12 ≤ k ≤ 13	0~9	48 ≤ d ≤ 57
		(EAN13)			
	3	JAN8 (EAN8)	7 ≤ k ≤ 8	0~9	48 ≤ d ≤ 57
				0~9,	$45 \le d \le 57,$
				A∼Z,	$65 \le d \le 90$ ,
1	4	CODE39	1 ≤ k ≤ 255	SP, \$, %, +,	d = 32, 36, 37, 43,
				-, .,/	45, 46, 47
				* (on/off)	d = 42(on/off)
	5	ITF	1 ≤ k ≤255 (even)	0~9	48 ≤ d ≤ 57
				0~9,	48 ≤ d ≤ 57,
	6		1 < k < 255	A∼D	65 ≤ d ≤ 68,
	0	CODABAN	1 3 K 3 200	\$, +, -, .,	d = 36, 43, 45, 46,
				/,:	47, 58
	65	UPC-A	11 ≤ n ≤ 12	0~9	48 ≤ d ≤ 57
	66	UPC-E	11 ≤ n ≤ 12	0~9	48 ≤ d ≤ 57
	67	JAN13	12 ≤ n ≤ 13	0~9	48 ≤ d ≤ 57
		(EAN13)			
	68	JAN8 (EAN8)	7 ≤ n ≤ 8	0~9	48 ≤ d ≤ 57
				0∼9,	$45 \le d \le 57,$
				A∼Z,	$65 \le d \le 90$ ,
	69	CODE39	1 ≤ n ≤ 255	SP, \$, %, +, -,	d = 32, 36, 37, 43, 45,
2				., /	46, 47
				* ((on/off))	d = 42((on/off))
	70	ITF	$1 \le n \le 255$ (even)	0~9	48 ≤ d ≤ 57
	71	CODABAR	1 ≤ n ≤ 255	0~9,	48 ≤ d ≤ 57,
				A∼D	65 ≤ d ≤ 68,
				\$, +, -, .,	d = 36, 43, 45, 46,
				/,:	47, 58
	72	CODE93	1 ≤ n ≤ 255	NUL~SP(7FH)	0 ≤ d ≤ 127
	73	CODE128	2 ≤ n ≤ 255	NUL~SP(7FH)	0 ≤ d ≤ 127

[Details for (1)]

. This command ends with a NUL code.

. When the bar code system used is UPC-A or UPC-E, the printer prints the bar code data after receiving 12 bytes bar code data and processes the following data as normal data.

. When the bar code system used is JAN13 (EAN13), the printer prints the bar code after receiving 13 bytes bar code data and processes the following data as normal data.

. When the bar code system used is JAN8 (EAN8), the printer prints the bar code after receiving 8 bytes bar code data and processes the following data as normal data.

. The number of data for ITF bar code must be even numbers. When an odd number of data is input, the printer ignores the last received data.

[Details for 2]

- . *n* indicates the number of bar code data, and the printer processes *n* bytes from the next character data as bar code data.
- . If *n* is outside of the specified range, the printer stops command processing an processes the following data as normal data.

[Details in standard mode]

- . If *d* is outside of the specified range, the printer only feeds paper and processes the following data as normal data.
- . If the horizontal size exceeds printing area, the printer only feeds the paper.
- . This command feeds as much paper as is required to print the bar code, regardless of the line spacing specified by **ESC 2** or **ESC 3**.
- . This command is enabled only when no data exists in the print buffer. When data exists in the print buffer, the printer processes the data following m as normal data.
- . After printing bar code, this command sets the print position to the beginning of the line.
- . This command is not affected by print modes (emphasized, double-strike, underline, character size, white/black reverse printing, or 90° rotated character, etc.), except for upside-down printing mode.

[Details in page mode]

- . This command develops bar code data in the print buffer, but does not print it. After processing bar code data, this command moves the print position to the right side dot of the bar code.
- . If *d* is out of the specified range, the printer stops command processing and processes the following data as normal data. In this case the data buffer position does not change.
- . If bar code width exceeds the printing area, the printer does not print the bar code but moves the data buffer position to the left side out of the printing area.

When CODE128 (m = 73) is used:

- Refer appendix A, CODE 128 coding as following:
  - Before making barcode data, choose one type of character from CODE A, CODE B and CODE C.
  - ② Sending "{" and another character to choose character type. Sending "{" for two times to get ASCII characters.

Specific	Sending data				
character	ASCII	Hex	Decimal		
SHIFT	{S	7B, 53	123,83		
CODE A	{A	7B, 41	123, 65		
CODE B	{B	7B, 42	123, 66		
CODE C	{C	7B, 43	123, 67		
FNC1	{1	7B, 31	123, 49		
FNC2	{2	7B, 32	123, 50		
FNC3	{3	7B, 33	123, 51		
FNC4	{4	7B, 34	123, 52		
"{"	{{	7B, 7B	123, 123		

[For example] Print "No. 123456"

Print "No." by CODE B, and then print next numbers by CODE C **GS k** 73 10 123 66 78 111 46 123 67 12 34 56



- If it is not character option before barcode data, printer will stop excuting this command, and excute following as simple data.
- " "{" +character" is not appointed string, printer will stop excuting command, and excute following as simple data.
- If the data printer received is not barcode data, printer will stop excuting this command, and excute following as simple data.
- .When printer prints an HRI character, without printing SHIFT characters and character type data.
- HRI characters for function won't be printed out.
- HRI of controlling character (<00>H to <1F>H and <7F>H) won't be printed out.

<Addition> Must be with spacing betweenleft and right side,gap is different with different barcode.

[Reference] GS H, GS f, GS h, GS w

## 61、 GS r n

[Name]	Transmit status				
[Format]	ASCII	GS	r	n	
	Hex	1D	72	n	
	Decimal	29	114	n	

[Range] *n* = 1, 2, 49, 50

[Description] Transmits the status specified by *n* as follows:

n	Function
1, 49	Transmits paper sensor status
2, 50	Transmits drawer kick-out connector status

[Details] . This command is only available for serial interface

. This command is executed when the data in the receive buffer is operated. Therefore, there may be a time lag between receiving this command and transmitting the status, depending on the receive buffer status.

. The status types to be transmitted are shown below:

Paper sensor	status	(n =	1.49):
1 4001 0011001	otatao	(''	.,

Bit	0/1	Hex	Decimal	Status for ASB
0,1	0	00	0	Paper roll near-end sensor: paper adequate.
	1	03	3	Paper roll near-end sensor: paper near end.
2,3	0	00	0	Paper roll end sensor: paper adequate.
	1	0C	12	Paper roll near-end sensor: paper near end.
4	0	00	0	Not used. Fixed to 0.

5,6	-	-	-	Undefined.
7	0	00	0	Not used. Fixed to 0.

#### Cash drawer (n = 2, 50):

Bit	0/1	Hex	Decimal	Status
0	0	00	0	Drawer kick-out
	1	01	1	Drawer doesn't kick-out
1-3				undefined
4	0	00	0	Not used. Fixed to 0
5,6				undefined
7	0	00	0	Not used. Fixed to 0

[Reference] DLE EOT, GS a

#### 62. GS v 0 m xL xH yL yH d1...dk

[Name]	Print raster bit image				
[Format]	ASCII GS v 0 m xL xH yL yH d1dk				
	Hex 1D 76 30 m xL xH yL yH d1dk				
	Decimal 29 118 48 m xL xH yL yH d1dk				
[Range]	$0 \leq m \leq 3, \ 48 \leq m \leq 51$				
	$0 \le xL \le 255$				
	$0 \le xH \le 255$				
	$0 \le yL \le 255$				
	$0 \le d \le 255$				
	k = ( xL + xH × 256) × ( yL + yH × 256) ( k $\neq$ 0)				
[Description]	Selects Raster bit-image mode. selects the mode by "m" value, as follows:				

m	Mode	Vertical Dot Density	Horizontal Dot ensity
0, 48	Normal	200 DPI	200 DPI
1, 49	Double-width	200 DPI	100 DPI
2, 50	Double-height	100 DPI	200 DPI
3, 51	Quadruple	100 DPI	100 DPI

- xL, xH, select the number of data bits ( xL+ xH×256) in the horizontal direction for the bit image.
- yL, yH, select the number of data bits (yL+ yH×256) in the vertical direction for the bit image.
- [Details]
- In standard mode, this command is effective only when there is no data in the print buffer.
- This command is invalid for character size, emphasized,double-strike, upside-down, underline, white/black reverse printing, etc.
- Image beyond print area won't be printed out.
- The ESC a (Select justification) setting is also effective on raster bit images.
- When this command is received during macro definition, the printer cancel macro definition, and begins performing this command. This command is not one part of macro definition.

• d indicates the bit-image data. Set time a bit to 1 prints the dot and setting it to 0 does not print the dot.

[For example]  $xL+ xH \times 256 = 64$ 



#### <u>63. GS w n</u>

[Name]	Set bar code width					
[Format]	ASCII	GS	W	n		
	Hex	1D	77	n		
	Decimal	29	119	n		

[Range] 2≤ *n*≤6

[Description] Set the horizontal size of the bar code.

*n* specifies the bar code width as follows:

n	Module Width (mm) for	Binary-level bar codes			
	Multi-level Bar Code	Thin element width (mm)	Thick element width (mm)		
2	0.25	0.25	0.625		
3	0.375	0.375	1.0		
4	0.5	0.5	1.25		
5	0.625	0.625	1.625		
6	0.75	0.75	1.875		

. Multi-level bar codes are as follows:

UPC-A, UPC-E, JAN13 (EAN13), JAN8 (EAN8), CODE93, CODE128 . Binary-level bar codes are as follows:

CODE39, ITF, CODABAR

[Default] n = 3[Reference] **GS k** 

# Kanji charaters command list

# 64. FS ! n

[Name] Set print mode(s) for Kanji characters

[Format]	ASCII	FS	!	n
	Hex	1C	21	n
	Decimal	28	33	n

[Range]  $0 \le n \le 255$ 

[Description] Sets the print mode for Kanji characters, using n as follows:

Bit	0/1	Hex	Decimal	Function
0, 1				Undefined
	0	00	0	Double-width
2				mode is OFF.
2	1	04	4	Double-width
				mode is ON.
3	0	00	0	Double-height
				mode is OFF.
	1	08	8	Double-height
				mode is ON.
4-6				Undefined
7	0	00	0	Underline OFF
'	1	80	128	Underline ON

### [Details]

• When both double-width and double-height modes are set (including right- and left-side character spacing), quadruple-size characters are printed.

- The printer can underline all characters (including right- and left-side character spacing), but cannot underline the space set by **HT** and 90° clockwise-rotated characters.
- The thickness of the underline is that specified by  $\textbf{FS} \ \square$  , regardless of the character size.
- When some of the characters in a line are double or more height, all the characters on the line are aligned at the baseline.
- It is possible to emphasize the Kanji character using **FSW** or **GS**!, the setting of the last received command is effective.
- It is possible to turn under line mode on or off using  $\textbf{FS} \ \square$  , and the setting of the last received command is effective.

[Default] n = 0

[Reference] FS -, FS W, GS !

## 65. FS &

[Name]	Select Kanji character mode					
[Format]	ASCII	FS	&			
	Hex	1C	26			
	Decimal	28	38			
	.10.1		1			

[Description] Selects Kanji character mode.

[Reference] FS.

# 66. FS - n

[Name]	Turn underl	ine mode (	on/off for k	Kanji characters			
[Format]	ASCII	FS	-	n			
	Hex	1C	2D	n			
	Decimal	28	45	n			
[Range]	$0 \le n \le 2, 48$	$3 \le n \le 50$					
[Description]	Turns under	rline mode	for Kanji d	characters on or off, based on the following values			
	of <i>n</i> .						
	<i>n</i> Function						
	0, 48	Turns off underline mode for Kanji characters					
	1, 49	Turns or	n underline	e mode for Kanji characters (1-dot thick)			
	2, 50 Turns on underline mode for Kanji characters (2-dot thick)						
[Details]	<ul> <li>The print spacing), characters</li> <li>After the u underline thickness</li> <li>The specichanges.</li> <li>It is possib command</li> </ul>	ter can underline all characters (including right- and left-side character but cannot underline the space set by <b>HT</b> and 90° clockwise-rotated 's. underline mode for Kanji characters is turned off by setting <i>n</i> to 0, printing is no longer performed, but the previously specified underline is not changed. The default underline thickness is 1 dot. ified line thickness does not change even when the character size ble to turn underline mode on or off using <b>FS</b> !, and the last received this effective					
[Default]	<i>n</i> = 0	-					
[Reference]	FS !						

# 67. FS.

[Name]	Cancel Kanji character mode					
[Format]	ASCII	FS				
	Hex	1C	2E			
	Decimal	28	46			
[Description] Cancels nKanji character mode.						
[Reference	e] FS &					

# 68. FS 2 c1 c2 d1...dk

[Name]	Define use	Define user-defined Kanji characters				
[Format]	ASCII	FS	2	c1	с2	d1dk
	Hex	1C	32	c1	с2	d1dk
	Decimal	28	50	c1	с2	d1dk
	c1 = FEH A1H ≤ c2 ≤ FEH					
	0 ≤ d ≤ 255					

k = 72

[Description] Defines user-defined Kanji characters for the character codes specified by *c1* and *c2*.

[Details]

- *c1* and *c2* indicate character codes for the defined characters. *c1* specifies for the first byte, and *c2* for the second byte.
- *d* indicates the dot data. Set a corresponding bit to 1 to print a dot or to 0 to not print a dot.
- [Default] All spaces.

#### [Reference] FS C

[Default] No defined Kanji

Relation between User-defined Chinese character and data:



## 69. FS S n1 n2

[Name]

Set left- and right-side Kanji character spacing

[Format]	ASCII	FS	S	n 1	n2	
	Hex	1C	53	n 1	n2	
	Decimal	28	83	n 1	n2	
[Range]	$0 \le n \ 1 \le 25$	55				
	$0 \le n 2 \le 2$	55				
[Description]	Sets left- a	nd right-si	de Kanji	characte	er spacing <i>n1</i> and <i>n2</i> , respectively.	
	• When the [ $n1 \times$ h [ $n2 \times$ h	e printer n orizontal ( orizontal	nodel use or vertical or vertica	d suppo motion I motion	orts <b>GS P</b> , the left-side character spacing is n units], and the right-side character spacing n units].	is
[Details]	• When o	louble-wi	dth mode	is set, tl	the left- and right-side character spacing is	
	The horiz	contal and	vertical r	notion u	units are set by <b>GS P</b> . The previously	
	specified	characte	r spacing	does no	ot change, even if the horizontal or vertical	
	motion u	hit is chan	iged using	g GS P.	Lation unit is used	
	• In stanua	node the	horizonta	ontai mu	tical motion unit differs in page mode	
	dependir	noue, the	ina positi	on of the	ne printable area as follows:	
	① When	the starti	ng positio	on is set	t to the upper left or lower right of the	
	printa	ble area	using <b>ES</b>	CT, the	e horizontal motion unit (x) is used.	
	2 When	the starti	ng positio	on is set	t to the upper right or lower left of the	
	printa	ble area	using <b>ES</b>	CT, the	e vertical motion unit ( y) is used.	
	appro maxii	oximately num auto	36mm. A	spacing ny settir	ng exceeding the maximum is converted to t	the
[Default]	<i>n1</i> = 0, <i>n</i> 2 =	0				
[Reference]	GS P					

# 70. FS W n

Turn quadruple-size mode on/off for Kanji characters						
ASCII	FS	W	n			
Hex	1C	57	n			
Decimal	28	87	n			
$0 \le n \le 255$						
Turns quadr	uple-size	mode on	or off for	Kanji characters.		
<ul><li>When th</li><li>When th</li></ul>	e LSB of e LSB of	n is 0, qua n is 1, qua	adruple-s adruple-s	ize mode for Kanji characters is turned off. ize mode for Kanji characters is turned on.		
<ul> <li>Only the</li> </ul>	lowest bi	t of <i>n</i> is va	lid.			
<ul> <li>In quadrude</li> <li>double-v</li> </ul>	uple-size vidth and	mode, the double-he	e printer p eight mod	prints with same size characters as when les are both turned on.		
<ul> <li>When quadruple-size mode is turned off using this command, the following characters are printed in normal size.</li> </ul>						
<ul> <li>When some of the characters on a line are different in height, all the characters on the line are aligned at the baseline.</li> </ul>						
• FS ! or GS ! can also select and cancel quadruple-size mode by selecting						
double-h comman	neight and nd is effec	d double-v tive.	vidth mod	es, and the setting of the last received		
<i>n</i> = 0						
FS !, GS !						
	Turn quadru ASCII Hex Decimal $0 \le n \le 255$ Turns quadr • When th • When th • Only the • In quadr double-v • When quadru characte • When quadru characte • When so on the lin • FS ! or C double-h comman n = 0 FS !, GS !	Turn quadruple-sizeASCIIFSHex1CDecimal28 $0 \le n \le 255$ Turns quadruple-size• When the LSB of• When the LSB of• When the LSB of• Only the lowest bit• In quadruple-sizedouble-width and• When quadruple-sizedouble-width and• When some of the on the line are alig• FS ! or GS ! can a double-height and command is effect $n = 0$ FS !, GS !	Turn quadruple-size mode on/aASCIIFSWHex1C57Decimal2887 $0 \le n \le 255$ Turns quadruple-size mode on• When the LSB of n is 0, qual• When the LSB of n is 1, qual• Only the lowest bit of n is val• In quadruple-size mode, the double-width and double-he• When quadruple-size mode, the double-width and double-he• When some of the characters on the line are aligned at th• FS ! or GS ! can also select double-height and double-width and double-width $n = 0$ FS !, GS !	Turn quadruple-size mode on/off for KanASCIIFSWnHex1C57nDecimal2887n $0 \le n \le 255$ Turns quadruple-size mode on or off for• When the LSB of n is 0, quadruple-si• When the LSB of n is 0, quadruple-si• When the LSB of n is 1, quadruple-si• Only the lowest bit of n is valid.• In quadruple-size mode, the printer p double-width and double-height mod• When quadruple-size mode is turned characters are printed in normal size• When some of the characters on a lin on the line are aligned at the baseline• FS ! or GS ! can also select and can double-height and double-width mod command is effective. $n = 0$ FS !, GS !		

# **Beeping commands**

# 71. ESC B n t

[Name]	Beeping on print	(TP-300K						
[Format]	ASCII	ESC	В	n	t			
	Hex	1B	42	n	t			
	Decimal	27	66	n	t			
[Range]	1<=n<=9, 1<=t	<=9						
[Description]	on] printer beeps when it get a printing job.							
<ul> <li>n indicates times of beeping</li> </ul>								
<ul> <li>t indicates beeping time (t × 50)ms.</li> </ul>								

# 72. ESC C m t n

[Name]	Beeping when pri	intout and	d indiator	flashing	g (	TP -300K series)
[Format]	ASCII	ESC	С	m	t	n
	Hex	1B	43	m	t	n
	Decimal	27	67	m	t	n
[Range]	1<=m<=20, 1<=	t<=20,0	<=n<=3,			
[Description]	Beeping whe	en printou	t and indi	iator flas	shing.	
	• m: 1<=m<=20,	times of	r flashin	ig or b	peeper sound	
	• t: 1<=t<=20, ti	me spaci	ng betwe	en indio	cator f	lashing, or beeper sound (t*50 ms)
	•n=0, no beeping	, indicato	r not flasł	ning		
	n=1, beeping					
	n=2, indicator fla	ashing				
	n=3, beeping an	d indicate	or flashing	g.		

## **APPDENIX X: 128 code**

## X.1 128 Introduction:

128 code can alternate from character A, B, C, and code 128 ASCII characters, numbers from00~99, each character set as following:

- Character A: ASCII character 00H ~ 5FH
- Character B: ASCII character 20H ~ 7FH
- Character C: numbers 00~99
- 128code can code following character:
- SHIFT characters

"SHIFT" convert the first character A following barcode SHIFT character to character B, or covert from character B to character. From the second character, will return back to character set before SHIFT, SHIFT characters only can alternated from character A and B, it can not use character C.

• Character options (CODE A、CODE B、 CODE C)

These characters can convert following characters into character A, B, C.

• Function characters (FNC1、 FNC2、FNC3、FNC4)

These characters are used for application software, only FNC1 is available in character C.

# X.2 Character Set

#### Character A

Char	Sending	g data	Chor	Sendir	ng data	ohor	Sendir	ng data
Char	Hex	Decimal	Char	Hex	Decimal	Cital	Hex	Decimal
NUL	00	0	(	28	40	Р	50	80
L	01	1	)	29	41	Q	51	81
SOH	02	2	*	2A	42	R	52	82
STX	03	3	+	2B	43	S	53	83
ETX	04	4	,	2C	44	Т	54	84
EOT	05	5	-	2D	45	U	55	85
ENQ	06	6		2E	46	V	56	86
ACK	07	7	/	2F	47	W	57	87
BEL	08	8	0	30	48	Х	58	88
BS	09	9	1	31	49	Υ	59	89
HT	0A	10	2	32	50	Z	5A	90
LF	0B	11	3	33	51	[	5B	91
VT	0C	12	4	34	52	١	5C	92
FF	0D	13	5	35	53	]	5D	93
CR	0E	14	6	36	54	^	5E	94
SO	0F	15	7	37	55	_	5F	95
SI	10	16	8	38	56	FNC	7B,31	123,49
DLE	11	17	9	39	57	1	7B,32	123,50
DC1	12	18	:	ЗA	58	FNC	7B,33	123,51
DC2	13	19	;	3B	59	2	7B,34	123,52
DC3	14	20	<	3C	60	FNC	7B,53	123,83
DC4	15	21	=	3D	61	3	7B,42	123,66
NAK	16	22	>	3E	62	FNC	7B,43	123,67
SYN	17	23	?	3F	63	4		
ETB	18	24	@	40	64	SHIF		
CAN	19	25	А	41	65	Т		
EM	1A	26	В	42	66	COD		
SUB	1B	27	С	43	67	EB		
ESC	1C	28	D	44	68	COD		
FS	1D	29	E	45	69	EC		
GS	1E	30	F	46	70			

RS	1F	31	G	47	71		
US	20	32	н	48	72		
SP	21	33	I	49	73		
!	22	34	J	4A	74		
"	23	35	К	4B	75		
*	24	36	L	4C	76		
\$	25	37	М	4D	77		
%	26	38	Ν	4E	78		
&	27	39	0	4F	79		

Char	Sending	ding data	Char Send		ng data	char	Sending data	
Cilai	Hex	Decimal	Cilai	Hex	Decimal	Hex	Decimal	十进制码
SP	20	32	Н	48	72	р	70	112
!	21	33	1	49	73	q	71	113
"	22	34	J	4A	74	r	72	114
*	23	35	к	4B	75	s	73	115
\$	24	36	L	4C	76	t	74	116
%	25	37	М	4D	77	u	75	117
&	26	38	N	4E	78	v	76	118
'	27	39	0	4F	79	w	77	119
(	28	40	Р	50	80	х	78	120
)	29	41	Q	51	81	у	79	121
*	2A	42	R	52	82	z	7A	122
+	2B	43	S	53	83	{	7B,7B	123,123
,	2C	44	Т	54	84	1	7C	124
-	2D	45	U	55	85	}	7D	125
	2E	46	V	56	86	—	7E	126
/	2F	47	W	57	87	DEL	7F	127
0	30	48	Х	58	88	FNC	7B,31	123,49
1	31	49	Y	59	89	1	7B,32	123,50
2	32	50	Z	5A	90	FNC	7B,33	123,51
3	33	51	[	5B	91	2	7B,34	123,52
4	34	52	١	5C	92	FNC	7B,53	123,83
5	35	53	]	5D	93	3	7B,41	123,65
6	36	54	^	5E	94	FNC	7B,43	123,67
7	37	55	_	5F	95	4		
8	38	56	Ì	60	96	SHIF		
9	39	57	а	61	97	Т		
:	ЗA	58	b	62	98	COD		
;	3B	59	с	63	99	EA		
<	3C	60	d	64	100	COD		
=	3D	61	е	65	101	EC		
>	3E	62	f	66	102			
?	3F	63	g	67	103			
@	40	64	h	68	104			
А	41	65	i	69	105			
В	42	66	j	6A	106			
С	43	67	k	6B	107			
D	44	68		6C	108			
E	45	69	m	6D	109			
F	46	70	n	6E	110			
G	47	71	0	6F	111			

Character B

Character	С
-----------	---

Char	Sending data		Char	Sending data		char	Sendir	ng data
Unar	Hex	Decimal	Char	Hex	Decimal	Hex	Decimal	十进制码
0	00	0	40	28	40	80	50	80
1	01	1	41	29	41	81	51	81
2	02	2	42	2A	42	82	52	82
3	03	3	43	2B	43	83	53	83
4	04	4	44	2C	44	84	54	84
5	05	5	45	2D	45	85	55	85
6	06	6	46	2E	46	86	56	86
7	07	7	47	2F	47	87	57	87
8	08	8	48	30	48	88	58	88
9	09	9	49	31	49	89	59	89
10	0A	10	50	32	50	90	5A	90
11	0B	11	51	33	51	91	5B	91
12	0C	12	52	34	52	92	5C	92
13	0D	13	53	35	53	93	5D	93
14	0E	14	54	36	54	94	5E	94
15	0F	15	55	37	55	95	5F	95
16	10	16	56	38	56	96	60	96
17	11	17	57	39	57	97	61	97
18	12	18	58	ЗA	58	98	62	98
19	13	19	59	3B	59	99	63	99
20	14	20	60	3C	60	FNC	7B,31	123,49
21	15	21	61	3D	61	1	7B,41	123,65
22	16	22	62	3E	62	COD	7B,42	123,66
23	17	23	63	3F	63	EA		
24	18	24	64	40	64	COD		
25	19	25	65	41	65	EB		
26	1A	26	66	42	66			
27	1B	27	67	43	67			
28	1C	28	68	44	68			
29	1D	29	69	45	69			
30	1E	30	70	46	70			
31	1F	31	71	47	71			
32	20	32	72	48	72			
33	21	33	73	49	73			
34	22	34	74	4A	74			
35	23	35	75	4B	75			
36	24	36	76	4C	76			
37	25	37	77	4D	77			
38	26	38	78	4E	78			
39	27	39	79	4F	79			